

**Processes**



Multiprocess Welding


**Description**



Arc Welding Power Source And  
Wire Feeder

# Hobart<sup>®</sup>

## Multi-Handler<sup>™</sup> 200



Find us on 

 YouTube

[www.HobartWelders.com](http://www.HobartWelders.com)

**OWNER'S MANUAL**

# TABLE OF CONTENTS

<b>SECTION 1 – SAFETY PRECAUTIONS - READ BEFORE USING</b>	<b>1</b>
1-1. Symbol Usage	1
1-2. Arc Welding Hazards	1
1-3. Additional Hazards For Installation, Operation, And Maintenance	3
1-4. California Proposition 65 Warnings	4
1-5. Principal Safety Standards	4
1-6. EMF Information	4
<b>SECTION 2 – CONSIGNES DE SÉCURITÉ – LIRE AVANT UTILISATION</b>	<b>5</b>
2-1. Symboles utilisés	5
2-2. Dangers relatifs au soudage à l'arc	5
2-3. Symboles de dangers supplémentaires en relation avec l'installation, le fonctionnement et la maintenance	7
2-4. Proposition californienne 65 Avertissements	8
2-5. Principales normes de sécurité	8
2-6. Informations relatives aux CEM	8
<b>SECTION 3 – DEFINITIONS</b>	<b>9</b>
3-1. Additional Safety Symbols And Definitions	9
3-2. Miscellaneous Symbols And Definitions	10
<b>SECTION 4 – SPECIFICATIONS</b>	<b>11</b>
4-1. Serial Number And Rating Label Location	11
4-2. Software Licensing Agreement	11
4-3. Information About Default Weld Parameters And Settings	11
4-4. Unit Specifications For MIG (GMAW)	11
4-5. Unit Specifications For TIG (GTAW)	11
4-6. Unit Specifications For Stick (SMAW)	11
4-7. Environmental Specifications	12
4-8. Dimensions And Weight	12
4-9. Duty Cycle And Overheating For MIG (GMAW)	13
4-10. Duty Cycle And Overheating For TIG (GTAW)	14
4-11. Duty Cycle And Overheating For Stick (SMAW)	15
<b>SECTION 5 – INSTALLATION</b>	<b>16</b>
5-1. Selecting A Location	16
5-2. Multi-Voltage Plug (MVP) Connection	17
5-3. Electrical Service Guide	18
5-4. Input Power Extension Cord Data	18
5-5. Connecting 120 Volt Input Power	19
5-6. Connecting 1-Phase Input Power For 240 VAC	20
5-7. Generator / Inverter Requirements	21
5-8. Stick Welding Connections	22
5-9. TIG Welding Connections	23
5-10. Process/Polarity Table	24
5-11. MIG Welding Connections	24
5-12. MIG Gun Connection Inside Unit	25
5-13. Connecting Shielding Gas Supply	26
5-14. Installing Wire Spool And Adjusting Hub Tension	27
5-15. Threading Welding Wire	28
5-16. Removing MIG Gun To Replace With A Spool Gun	29

# TABLE OF CONTENTS

<b>SECTION 6 – OPERATION</b> .....	<b>30</b>
6-1. Controls .....	30
6-2. Screen, Power-Up Mode .....	31
6-3. Screen, Wire Jog Mode .....	31
6-4. Controls, MIG Mode (Menu 1 Of 5) .....	32
6-5. Controls, Flux Cored Mode (Menu 2 Of 5) .....	33
6-6. Controls, TIG Mode (Menu 3 Of 5) .....	34
6-7. Controls, TIG Mode With Foot Pedal(Menu 4 Of 5) .....	35
6-8. Controls, Stick Mode (Menu 5 Of 5) .....	36
6-9. Screen, Power-Down Mode .....	37
<b>SECTION 7 – WELD PARAMETER CHARTS</b> .....	<b>38</b>
7-1. Welding Parameters 120 Volt .....	38
7-2. Welding Parameters 240 Volt .....	40
<b>SECTION 8 – MAINTENANCE &amp; TROUBLESHOOTING</b> .....	<b>42</b>
8-1. Routine Maintenance .....	42
8-2. Overload Protection .....	42
8-3. Changing Drive Roll Or Wire Inlet Guide .....	43
8-4. Error Displays .....	44
8-5. Error Messages .....	45
8-6. Troubleshooting .....	46
<b>SECTION 9 – ELECTRICAL DIAGRAM</b> .....	<b>48</b>
<b>SECTION 10 – SELECTING AND PREPARING A TUNGSTEN FOR DC OR AC WELDING WITH INVERTER MACHINES</b> .....	<b>50</b>
10-1. Selecting Tungsten Electrode (Wear Clean Gloves To Prevent Contamination Of Tungsten) .	50
10-2. Preparing Tungsten Electrode For DC Electrode Negative (DCEN) Welding Or AC Welding With Inverter Machines .....	51
<b>SECTION 11 – GUIDELINES FOR TIG WELDING (GTAW)</b> .....	<b>52</b>
11-1. Positioning The Torch .....	52
11-2. Torch Movement During Welding .....	53
11-3. Positioning Torch Tungsten For Various Weld Joints .....	53
11-4. Lift-Arc And HF TIG Start Procedures .....	54
<b>SECTION 12 – GMAW WELDING (MIG) GUIDELINES</b> .....	<b>55</b>
<b>SECTION 13 – GUIDELINES FOR STICK WELDING (SMAW)</b> .....	<b>63</b>
13-1. Stick Welding Procedure .....	63
13-2. Electrode And Amperage Selection Chart .....	64
13-3. Striking An Arc .....	64
13-4. Positioning Electrode Holder .....	65
13-5. Poor Weld Bead Characteristics .....	65
13-6. Good Weld Bead Characteristics .....	65
13-7. Conditions That Affect Weld Bead Shape .....	66
13-8. Electrode Movement During Welding .....	66
13-9. Welding Lap Joints .....	66
13-10. Welding Groove (Butt) Joints .....	67
13-11. Welding T-Joints .....	67
13-12. Weld Test .....	68
13-13. Troubleshooting .....	68
<b>SECTION 14 – PARTS LIST</b> .....	<b>70</b>
14-1. Parts List .....	70
14-2. Recommended MIG Spare Parts .....	70
14-3. Recommended TIG Spare Parts .....	70

**COMPLETE PARTS LIST – Available at [www.HobartWelders.com](http://www.HobartWelders.com)**

**WARRANTY**

# SECTION 1 – SAFETY PRECAUTIONS - READ BEFORE USING

som 2020-02

**⚠** Protect yourself and others from injury — read, follow, and save these important safety precautions and operating instructions.

## 1-1. Symbol Usage



**DANGER!** – Indicates a hazardous situation which, if not avoided, will result in death or serious injury. The possible hazards are shown in the adjoining symbols or explained in the text.



Indicates a hazardous situation which, if not avoided, could result in death or serious injury. The possible hazards are shown in the adjoining symbols or explained in the text.

**NOTICE** – Indicates statements not related to personal injury.

 Indicates special instructions.



This group of symbols means Warning! Watch Out! ELECTRIC SHOCK, MOVING PARTS, and HOT PARTS hazards. Consult symbols and related instructions below for necessary actions to avoid these hazards.

## 1-2. Arc Welding Hazards



The symbols shown below are used throughout this manual to call attention to and identify possible hazards. When you see the symbol, watch out, and follow the related instructions to avoid the hazard. The safety information given below is only a summary of the more complete safety information found in the Principal Safety Standards listed in Section 1-5. Read and follow all Safety Standards.



Only qualified persons should install, operate, maintain, and repair this equipment. A qualified person is defined as one who, by possession of a recognized degree, certificate, or professional standing, or who by extensive knowledge, training and experience, has successfully demonstrated the ability to solve or resolve problems relating to the subject matter, the work, or the project and has received safety training to recognize and avoid the hazards involved.



During operation, keep everybody, especially children, away.



### ELECTRIC SHOCK can kill.

Touching live electrical parts can cause fatal shocks or severe burns. The electrode and work circuit is electrically live whenever the output is on. The input power circuit and machine internal circuits are also live when power is on. In semiautomatic or automatic wire welding, the wire, wire reel, drive roll housing, and all metal parts touching the welding wire are electrically live. Incorrectly installed or improperly grounded equipment is a hazard.

- Do not touch live electrical parts.

- Wear dry, hole-free insulating gloves and body protection.
- Insulate yourself from work and ground using dry insulating mats or covers big enough to prevent any physical contact with the work or ground.
- Do not use AC weld output in damp, wet, or confined spaces, or if there is a danger of falling.
- Use AC output ONLY if required for the welding process.
- If AC output is required, use remote output control if present on unit.
- Additional safety precautions are required when any of the following electrically hazardous conditions are present: in damp locations or while wearing wet clothing; on metal structures such as floors, gratings, or scaffolds; when in cramped positions such as sitting, kneeling, or lying; or when there is a high risk of unavoidable or accidental contact with the workpiece or ground. For these conditions, use the following equipment in order presented: 1) a semiautomatic DC constant voltage (wire) welder, 2) a DC manual (stick) welder, or 3) an AC welder with reduced open-circuit voltage. In most situations, use of a DC, constant voltage wire welder is recommended. And, do not work alone!
- Disconnect input power or stop engine before installing or servicing this equipment. Lockout/tagout input power according to OSHA 29 CFR 1910.147 (see Safety Standards).

- Properly install, ground, and operate this equipment according to its Owner's Manual and national, state, and local codes.
- Always verify the supply ground – check and be sure that input power cord ground wire is properly connected to ground terminal in disconnect box or that cord plug is connected to a properly grounded receptacle outlet.
- When making input connections, attach proper grounding conductor first – double-check connections.
- Keep cords dry, free of oil and grease, and protected from hot metal and sparks.
- Frequently inspect input power cord and ground conductor for damage or bare wiring – replace immediately if damaged – bare wiring can kill.
- Turn off all equipment when not in use.
- Do not use worn, damaged, undersized, or repaired cables.
- Do not drape cables over your body.
- If earth grounding of the workpiece is required, ground it directly with a separate cable.
- Do not touch electrode if you are in contact with the work, ground, or another electrode from a different machine.
- Do not touch electrode holders connected to two welding machines at the same time since double open-circuit voltage will be present.
- Use only well-maintained equipment. Repair or replace damaged parts at once. Maintain unit according to manual.
- Wear a safety harness if working above floor level.
- Keep all panels and covers securely in place.
- Clamp work cable with good metal-to-metal contact to workpiece or worktable as near the weld as practical.
- Insulate work clamp when not connected to workpiece to prevent contact with any metal object.
- Do not connect more than one electrode or work cable to any single weld output terminal. Disconnect cable for process not in use.
- Use GFCI protection when operating auxiliary equipment in damp or wet locations.

### SIGNIFICANT DC VOLTAGE exists in inverter welding power sources AFTER removal of input power.

- Turn off unit, disconnect input power, and discharge input capacitors according to instructions in Manual before touching any parts.



### HOT PARTS can burn.

- Do not touch hot parts bare handed.
- Allow cooling period before working on equipment.
- To handle hot parts, use proper tools and/or wear heavy, insulated welding gloves and clothing to prevent burns.



### FUMES AND GASES can be hazardous.

Welding produces fumes and gases. Breathing these fumes and gases can be hazardous to your health.

- Keep your head out of the fumes. Do not breathe the fumes.
- Ventilate the work area and/or use local forced ventilation at the arc to remove welding fumes and gases. The recommended way to determine adequate ventilation is to sample for the composition and quantity of fumes and gases to which personnel are exposed.
- If ventilation is poor, wear an approved air-supplied respirator.
- Read and understand the Safety Data Sheets (SDSs) and the manufacturer's instructions for adhesives, coatings, cleaners, consumables, coolants, degreasers, fluxes, and metals.
- Work in a confined space only if it is well ventilated, or while wearing an air-supplied respirator. Always have a trained watchperson nearby. Welding fumes and gases can displace air and lower the oxygen level causing injury or death. Be sure the breathing air is safe.
- Do not weld in locations near degreasing, cleaning, or spraying operations. The heat and rays of the arc can react with vapors to form highly toxic and irritating gases.
- Do not weld on coated metals, such as galvanized, lead, or cadmium plated steel, unless the coating is removed from the weld area, the area is well ventilated, and while wearing an air-supplied respirator. The coatings and any metals containing these elements can give off toxic fumes if welded.



### ARC RAYS can burn eyes and skin.

Arc rays from the welding process produce intense visible and invisible (ultraviolet and infrared) rays that can burn eyes and skin. Sparks fly off from the weld.

- Wear an approved welding helmet fitted with a proper shade of filter lenses to protect your face and eyes from arc rays and sparks when welding or watching (see ANSI Z49.1 and Z87.1 listed in Safety Standards).
- Wear approved safety glasses with side shields under your helmet.
- Use protective screens or barriers to protect others from flash, glare and sparks; warn others not to watch the arc.
- Wear body protection made from durable, flame-resistant material (leather, heavy cotton, wool). Body protection includes oil-free clothing such as leather gloves, heavy shirt, cuffless trousers, high shoes, and a cap.




### WELDING can cause fire or explosion.

Welding on closed containers, such as tanks, drums, or pipes, can cause them to blow up. Sparks can fly off from the welding arc. The flying sparks, hot workpiece, and hot equipment can cause fires and burns. Accidental contact of electrode to metal objects can cause sparks, explosion, overheating, or fire. Check and be sure the area is safe before doing any welding.

- Remove all flammables within 35 ft (10.7 m) of the welding arc. If this is not possible, tightly cover them with approved covers.
- Do not weld where flying sparks can strike flammable material.
- Protect yourself and others from flying sparks and hot metal.
- Be alert that welding sparks and hot materials from welding can easily go through small cracks and openings to adjacent areas.
- Watch for fire, and keep a fire extinguisher nearby.
- Be aware that welding on a ceiling, floor, bulkhead, or partition can cause fire on the hidden side.

- Do not cut or weld on tire rims or wheels. Tires can explode if heated. Repaired rims and wheels can fail. See OSHA 29 CFR 1910.177 listed in Safety Standards.
- Do not weld on containers that have held combustibles, or on closed containers such as tanks, drums, or pipes unless they are properly prepared according to AWS F4.1 and AWS A6.0 (see Safety Standards).
- Do not weld where the atmosphere can contain flammable dust, gas, or liquid vapors (such as gasoline).
- Connect work cable to the work as close to the welding area as practical to prevent welding current from traveling long, possibly unknown paths and causing electric shock, sparks, and fire hazards.
- Do not use welder to thaw frozen pipes.
- Remove stick electrode from holder or cut off welding wire at contact tip when not in use.
- Wear body protection made from durable, flame-resistant material (leather, heavy cotton, wool). Body protection includes oil-free clothing such as leather gloves, heavy shirt, cuffless trousers, high shoes, and a cap.
- Remove any combustibles, such as a butane lighter or matches, from your person before doing any welding.
- After completion of work, inspect area to ensure it is free of sparks, glowing embers, and flames.
- Use only correct fuses or circuit breakers. Do not oversize or bypass them.
- Follow requirements in OSHA 1910.252 (a) (2) (iv) and NFPA 51B for hot work and have a fire watcher and extinguisher nearby.
- Read and understand the Safety Data Sheets (SDSs) and the manufacturer's instructions for adhesives, coatings, cleaners, consumables, coolants, degreasers, fluxes, and metals.



### FLYING METAL or DIRT can injure eyes.

- Welding, chipping, wire brushing, and grinding cause sparks and flying metal. As welds cool, they can throw off slag.
- Wear approved safety glasses with side shields even under your welding helmet.




### BUILDUP OF GAS can injure or kill.

- Shut off compressed gas supply when not in use.
- Always ventilate confined spaces or use approved air-supplied respirator.



### ELECTRIC AND MAGNETIC FIELDS (EMF) can affect Implanted Medical Devices.

- Wearers of Pacemakers and other Implanted Medical Devices should keep away.
- Implanted Medical Device wearers should consult their doctor and the device manufacturer before going near arc welding, spot welding, gouging, plasma arc cutting, or induction heating operations.



### NOISE can damage hearing.

Noise from some processes or equipment can damage hearing.

- Wear approved ear protection if noise level is high.



### CYLINDERS can explode if damaged.

Compressed gas cylinders contain gas under high pressure. If damaged, a cylinder can explode. Since gas cylinders are normally part of the welding process, be sure to treat them carefully.

- Protect compressed gas cylinders from excessive heat, mechanical shocks, physical damage, slag, open flames, sparks, and arcs.
- Install cylinders in an upright position by securing to a stationary support or cylinder rack to prevent falling or tipping.
- Keep cylinders away from any welding or other electrical circuits.
- Never drape a welding torch over a gas cylinder.
- Never allow a welding electrode to touch any cylinder.

- Never weld on a pressurized cylinder – explosion will result.
- Use only correct compressed gas cylinders, regulators, hoses, and fittings designed for the specific application; maintain them and associated parts in good condition.
- Turn face away from valve outlet when opening cylinder valve. Do not stand in front of or behind the regulator when opening the valve.
- Keep protective cap in place over valve except when cylinder is in use or connected for use.
- Use the proper equipment, correct procedures, and sufficient number of persons to lift, move, and transport cylinders.
- Read and follow instructions on compressed gas cylinders, associated equipment, and Compressed Gas Association (CGA) publication P-1 listed in Safety Standards.

## 1-3. Additional Hazards For Installation, Operation, And Maintenance




### FIRE OR EXPLOSION hazard.

- Do not install or place unit on, over, or near combustible surfaces.
- Do not install unit near flammables.
- Do not overload building wiring – be sure power supply system is properly sized, rated, and protected to handle this unit.




### FALLING EQUIPMENT can injure.

- Use lifting eye to lift unit only, NOT running gear, gas cylinders, or any other accessories.
- Use correct procedures and equipment of adequate capacity to lift and support unit.
- If using lift forks to move unit, be sure forks are long enough to extend beyond opposite side of unit.
- Keep equipment (cables and cords) away from moving vehicles when working from an aerial location.
- Follow the guidelines in the Applications Manual for the Revised NIOSH Lifting Equation (Publication No. 94-110) when manually lifting heavy parts or equipment.




### OVERUSE can cause OVERHEATING

- Allow cooling period; follow rated duty cycle.
- Reduce current or reduce duty cycle before starting to weld again.
- Do not block or filter airflow to unit.



### FLYING SPARKS can injure.

- Wear a face shield to protect eyes and face.
- Shape tungsten electrode only on grinder with proper guards in a safe location wearing proper face, hand, and body protection.
- Sparks can cause fires — keep flammables away.



### STATIC (ESD) can damage PC boards.

- Put on grounded wrist strap BEFORE handling boards or parts.
- Use proper static-proof bags and boxes to store, move, or ship PC boards.




### MOVING PARTS can injure.

- Keep away from moving parts.
- Keep away from pinch points such as drive rolls.



### WELDING WIRE can injure.

- Do not press gun trigger until instructed to do so.
- Do not point gun toward any part of the body, other people, or any metal when threading welding wire.




### BATTERY EXPLOSION can injure.

- Do not use welder to charge batteries or jump start vehicles unless it has a battery charging feature designed for this purpose.



### MOVING PARTS can injure.

- Keep away from moving parts such as fans.
- Keep all doors, panels, covers, and guards closed and securely in place.
- Have only qualified persons remove doors, panels, covers, or guards for maintenance and troubleshooting as necessary.
- Reinstall doors, panels, covers, or guards when maintenance is finished and before reconnecting input power.



### READ INSTRUCTIONS.


- Read and follow all labels and the Owner's Manual carefully before installing, operating, or servicing unit. Read the safety information at the beginning of the manual and in each section.
- Use only genuine replacement parts from the manufacturer.
- Perform installation, maintenance, and service according to the Owner's Manuals, industry standards, and national, state, and local codes.



#### H.F. RADIATION can cause interference.

- High-frequency (H.F.) can interfere with radio navigation, safety services, computers, and communications equipment.

- Have only qualified persons familiar with electronic equipment perform this installation.
- The user is responsible for having a qualified electrician promptly correct any interference problem resulting from the installation.
- If notified by the FCC about interference, stop using the equipment at once.
- Have the installation regularly checked and maintained.
- Keep high-frequency source doors and panels tightly shut, keep spark gaps at correct setting, and use grounding and shielding to minimize the possibility of interference.



#### ARC WELDING can cause interference.

- Electromagnetic energy can interfere with sensitive electronic equipment such as computers and computer-driven equipment such as robots.

- Be sure all equipment in the welding area is electromagnetically compatible.
- To reduce possible interference, keep weld cables as short as possible, close together, and down low, such as on the floor.
- Locate welding operation 100 meters from any sensitive electronic equipment.
- Be sure this welding machine is installed and grounded according to this manual.
- If interference still occurs, the user must take extra measures such as moving the welding machine, using shielded cables, using line filters, or shielding the work area.

### 1-4. California Proposition 65 Warnings

**⚠ WARNING: This product can expose you to chemicals including lead, which are known to the state of California to cause cancer and birth defects or other reproductive harm.**

For more information, go to [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov).

### 1-5. Principal Safety Standards

*Safety in Welding, Cutting, and Allied Processes*, American Welding Society standard ANSI Standard Z49.1. Website: [www.aws.org](http://www.aws.org).

*Safe Practice For Occupational And Educational Eye And Face Protection*, ANSI Standard Z87.1 from American National Standards Institute. Website: [www.ansi.org](http://www.ansi.org).

*Safe Practices for the Preparation of Containers and Piping for Welding and Cutting*, American Welding Society Standard AWS F4.1 from Global Engineering Documents. Website: [www.global.ihs.com](http://www.global.ihs.com).

*Safe Practices for Welding and Cutting Containers that have Held Combustibles*, American Welding Society Standard AWS A6.0 from Global Engineering Documents. Website: [www.global.ihs.com](http://www.global.ihs.com).

*National Electrical Code*, NFPA Standard 70 from National Fire Protection Association. Website: [www.nfpa.org](http://www.nfpa.org) and [www.sparky.org](http://www.sparky.org).

*Safe Handling of Compressed Gases in Cylinders*, CGA Pamphlet P-1 from Compressed Gas Association. Website: [www.cganet.com](http://www.cganet.com).

*Safety in Welding, Cutting, and Allied Processes*, CSA Standard W117.2 from Canadian Standards Association. Website: [www.csagroup.org](http://www.csagroup.org).

*Standard for Fire Prevention During Welding, Cutting, and Other Hot Work*, NFPA Standard 51B from National Fire Protection Association. Website: [www.nfpa.org](http://www.nfpa.org).

OSHA *Occupational Safety and Health Standards for General Industry*, Title 29, Code of Federal Regulations (CFR), Part 1910.177 Subpart N, Part 1910 Subpart Q, and Part 1926, Subpart J. Website: [www.osha.gov](http://www.osha.gov).

OSHA *Important Note Regarding the ACGIH TLV, Policy Statement on the Uses of TLVs and BEIs*. Website: [www.osha.gov](http://www.osha.gov).

*Applications Manual for the Revised NIOSH Lifting Equation* from the National Institute for Occupational Safety and Health (NIOSH). Website: [www.cdc.gov/NIOSH](http://www.cdc.gov/NIOSH).

### 1-6. EMF Information

Electric current flowing through any conductor causes localized electric and magnetic fields (EMF). The current from arc welding (and allied processes including spot welding, gouging, plasma arc cutting, and induction heating operations) creates an EMF field around the welding circuit. EMF fields can interfere with some medical implants, e.g. pacemakers. Protective measures for persons wearing medical implants have to be taken. For example, restrict access for passers-by or conduct individual risk assessment for welders. All welders should use the following procedures in order to minimize exposure to EMF fields from the welding circuit:

1. Keep cables close together by twisting or taping them, or using a cable cover.
2. Do not place your body between welding cables. Arrange cables to one side and away from the operator.
3. Do not coil or drape cables around your body.

4. Keep head and trunk as far away from the equipment in the welding circuit as possible.
5. Connect work clamp to workpiece as close to the weld as possible.
6. Do not work next to, sit or lean on the welding power source.
7. Do not weld whilst carrying the welding power source or wire feeder.

#### About Implanted Medical Devices:

Implanted Medical Device wearers should consult their doctor and the device manufacturer before performing or going near arc welding, spot welding, gouging, plasma arc cutting, or induction heating operations. If cleared by your doctor, then following the above procedures is recommended.

# SECTION 2 – CONSIGNES DE SÉCURITÉ – LIRE AVANT UTILISATION

som\_2020-02\_fre

**⚠** Pour écarter les risques de blessure pour vous-même et pour autrui — lire, appliquer et ranger en lieu sûr ces consignes relatives aux précautions de sécurité et au mode opératoire.

## 2-1. Symboles utilisés



**DANGER!** – Indique une situation dangereuse qui si on l'évite pas peut donner la mort ou des blessures graves. Les dangers possibles sont montrés par les symboles joints ou sont expliqués dans le texte.



Indique une situation dangereuse qui si on l'évite pas peut donner la mort ou des blessures graves. Les dangers possibles sont montrés par les symboles joints ou sont expliqués dans le texte.

**AVIS** – Indique des déclarations pas en relation avec des blessures personnelles.

Indique des instructions spécifiques.



Ce groupe de symboles veut dire Avertissement! Attention! DANGER DE CHOC ELECTRIQUE, PIECES EN MOUVEMENT, et PIECES CHAUDES. Reportez-vous aux symboles et aux directives ci-dessous afin de connaître les mesures à prendre pour éviter tout danger.

## 2-2. Dangers relatifs au soudage à l'arc



Les symboles représentés ci-dessous sont utilisés dans ce manuel pour attirer l'attention et identifier les dangers possibles. En présence de l'un de ces symboles, prendre garde et suivre les instructions afférentes pour éviter tout risque. Les consignes de sécurité présentées ci-après ne font que résumer les informations contenues dans les principales normes de sécurité énumérées à la section 2-5. Lire et observer toutes les normes de sécurité.



L'installation, l'utilisation, l'entretien et les réparations ne doivent être confiés qu'à des personnes qualifiées. Une personne qualifiée est définie comme celle qui, par la possession d'un diplôme reconnu, d'un certificat ou d'un statut professionnel, ou qui, par une connaissance, une formation et une expérience approfondies, a démontré avec succès sa capacité à résoudre les problèmes liés à la tâche, le travail ou le projet et a reçu une formation en sécurité afin de reconnaître et d'éviter les risques inhérents.



Pendant le fonctionnement, maintenir à distance toutes les personnes, notamment les enfants de l'appareil.



### UNE DÉCHARGE ÉLECTRIQUE peut entraîner la mort.

Le contact d'organes électriques sous tension peut provoquer des accidents mortels ou des brûlures graves. Le circuit de l'électrode et de la pièce est sous tension lorsque le courant est délivré à la sortie. Le circuit d'alimentation et les circuits internes de la machine sont également sous tension lorsque l'alimentation est sur Marche. Dans le mode de soudage avec du fil, le fil, le dérouleur, le bloc de commande du rouleau et toutes les parties métalliques en contact avec le fil sont sous tension électrique. Un équipement installé ou mis à la terre de manière incorrecte ou impropre constitue un danger.

- Ne pas toucher aux pièces électriques sous tension.
- Porter des gants isolants et des vêtements de protection secs et sans trous.
- S'isoler de la pièce à couper et du sol en utilisant des housses ou des tapis assez grands afin d'éviter tout contact physique avec la pièce à couper ou le sol.
- Ne pas utiliser de sortie de soudage CA dans des zones humides ou confinées ou s'il y a un risque de chute.
- Se servir d'une source électrique à courant électrique UNIQUEMENT si le procédé de soudage le demande.
- Si l'utilisation d'une source électrique à courant électrique s'avère nécessaire, se servir de la fonction de télécommande si l'appareil en est équipé.
- D'autres consignes de sécurité sont nécessaires dans les conditions suivantes : risques électriques dans un environnement humide ou si l'on porte des vêtements mouillés ; sur des structures métalliques telles que sols, grilles ou échafaudages ; en position coincée comme assise, à genoux ou couchée ; ou s'il y a un risque élevé de contact inévitable ou accidentel avec la pièce à souder ou le sol. Dans ces conditions, utiliser les équipements suivants, dans l'ordre indiqué : 1) un poste à souder DC à tension constante (à fil), 2) un poste à souder DC manuel (électrode) ou 3) un poste à souder AC à tension à vide réduite. Dans la plupart des situations,

l'utilisation d'un poste à souder DC à fil à tension constante est recommandée. En outre, ne pas travailler seul !

- Couper l'alimentation ou arrêter le moteur avant de procéder à l'installation, à la réparation ou à l'entretien de l'appareil. Déverrouiller l'alimentation selon la norme OSHA 29 CFR 1910.147 (voir normes de sécurité).
- Installez, mettez à la terre et utilisez correctement cet équipement conformément à son Manuel d'Utilisation et aux réglementations nationales, gouvernementales et locales.
- Toujours vérifier la terre du cordon d'alimentation. Vérifier et s'assurer que le fil de terre du cordon d'alimentation est bien raccordé à la borne de terre du sectionneur ou que la fiche du cordon est raccordée à une prise correctement mise à la terre.
- En effectuant les raccordements d'entrée, fixer d'abord le conducteur de mise à la terre approprié et contre-vérifier les connexions.
- Les câbles doivent être exempts d'humidité, d'huile et de graisse; protégez-les contre les étincelles et les pièces métalliques chaudes.
- Vérifier fréquemment le cordon d'alimentation et le conducteur de mise à la terre afin de s'assurer qu'il n'est pas altéré ou dénudé -, le remplacer immédiatement s'il l'est -. Un fil dénudé peut entraîner la mort.
- L'équipement doit être hors tension lorsqu'il n'est pas utilisé.
- Ne pas utiliser des câbles usés, endommagés, de grosseur insuffisante ou mal épissés.
- Ne pas enrouler les câbles autour du corps.
- Si la pièce soudée doit être mise à la terre, le faire directement avec un câble distinct.
- Ne pas toucher l'électrode quand on est en contact avec la pièce, la terre ou une électrode provenant d'une autre machine.
- Ne pas toucher des porte électrodes connectés à deux machines en même temps à cause de la présence d'une tension à vide doublée.
- N'utiliser qu'un matériel en bon état. Réparer ou remplacer sur-le-champ les pièces endommagées. Entretien l'appareil conformément à ce manuel.
- Porter un harnais de sécurité si l'on doit travailler au-dessus du sol.
- S'assurer que tous les panneaux et couvercles sont correctement en place.
- Fixer le câble de retour de façon à obtenir un bon contact métal-métal avec la pièce à souder ou la table de travail, le plus près possible de la soudure.
- Isoler la pince de masse quand pas mis à la pièce pour éviter le contact avec tout objet métallique.
- Ne pas raccorder plus d'une électrode ou plus d'un câble de masse à une même borne de sortie de soudage. Débrancher le câble pour le procédé non utilisé.
- Utiliser une protection différentielle lors de l'utilisation d'un équipement auxiliaire dans des endroits humides ou mouillés.

### Il reste une TENSION DC NON NÉGLIGEABLE dans les sources de soudage onduleur UNE FOIS l'alimentation coupée.

- Éteignez l'unité, débranchez le courant électrique, et déchargez les condensateurs d'alimentation selon les instructions indiquées dans le manuel avant de toucher les pièces.



### LES PIÈCES CHAUDES peuvent provoquer des brûlures.

- Ne pas toucher à mains nues les parties chaudes.
- Prévoir une période de refroidissement avant de travailler à l'équipement.

- Ne pas toucher aux pièces chaudes, utiliser les outils recommandés et porter des gants de soudage et des vêtements épais pour éviter les brûlures.



### LES FUMÉES ET LES GAZ peuvent être dangereux.

Le soudage génère des fumées et des gaz. Leur inhalation peut être dangereux pour votre santé.

- Eloigner votre tête des fumées. Ne pas respirer les fumées.
- À l'intérieur, ventiler la zone et/ou utiliser une ventilation forcée au niveau de l'arc pour l'évacuation des fumées et des gaz de soudage. Pour déterminer la bonne ventilation, il est recommandé de procéder à un prélèvement pour la composition et la quantité de fumées et de gaz auxquelles est exposé le personnel.
- Si la ventilation est médiocre, porter un respirateur anti-vapeurs approuvé.
- Lire et comprendre les fiches de données de sécurité et les instructions du fabricant concernant les adhésifs, les revêtements, les nettoyants, les consommables, les produits de refroidissement, les dégraissateurs, les flux et les métaux.
- Travailler dans un espace fermé seulement s'il est bien ventilé ou en portant un respirateur à alimentation d'air. Demander toujours à un surveillant dûment formé de se tenir à proximité. Des fumées et des gaz de soudage peuvent déplacer l'air et abaisser le niveau d'oxygène provoquant des blessures ou des accidents mortels. S'assurer que l'air de respiration ne présente aucun danger.
- Ne pas souder dans des endroits situés à proximité d'opérations de dégraissage, de nettoyage ou de pulvérisation. La chaleur et les rayons de l'arc peuvent réagir en présence de vapeurs et former des gaz hautement toxiques et irritants.
- Ne pas souder des métaux munis d'un revêtement, tels que l'acier galvanisé, plaqué en plomb ou au cadmium à moins que le revêtement n'ait été enlevé dans la zone de soudure, que l'endroit soit bien ventilé, et en portant un respirateur à alimentation d'air. Les revêtements et tous les métaux renfermant ces éléments peuvent dégager des fumées toxiques en cas de soudage.



### LES RAYONS DE L'ARC peuvent provoquer des brûlures dans les yeux et sur la peau.

Le rayonnement de l'arc du procédé de soudage génère des rayons visibles et invisibles intenses (ultraviolets et infrarouges) susceptibles de provoquer des brûlures dans les yeux et sur la peau. Des étincelles sont projetées pendant le soudage.


- Porter un casque de soudage approuvé muni de verres filtrants approprié pour protéger visage et yeux pour protéger votre visage et vos yeux pendant le soudage ou pour regarder (voir ANSI Z49.1 et Z87.1 énuméré dans les normes de sécurité).
- Porter des lunettes de sécurité avec écrans latéraux même sous votre casque.
- Avoir recours à des écrans protecteurs ou à des rideaux pour protéger les autres contre les rayonnements les éblouissements et les étincelles ; prévenir toute personne sur les lieux de ne pas regarder l'arc.
- Porter un équipement de protection pour le corps fait d'un matériau résistant et ignifuge (cuir, coton robuste, laine). La protection du corps comporte des vêtements sans huile comme par ex. des gants de cuir, une chemise solide, des pantalons sans revers, des chaussures hautes et une casquette.



### LE SOUDAGE peut provoquer un incendie ou une explosion.

Le soudage effectué sur des conteneurs fermés tels que des réservoirs, tambours ou des conduites peut provoquer leur éclatement. Des étincelles peuvent être projetées de l'arc de soudure. La projection d'étincelles, des pièces chaudes et des équipements chauds peut provoquer des incendies et des brûlures. Le contact accidentel de l'électrode avec des objets métalliques peut provoquer des étincelles, une explosion, un surchauffement ou un incendie. Avant de commencer le soudage, vérifier et s'assurer que l'endroit ne présente pas de danger.

- Déplacer toutes les substances inflammables à une distance de 10,7 m de l'arc de soudage. En cas d'impossibilité les recouvrir soigneusement avec des protections homologués.
- Ne pas souder dans un endroit où des étincelles peuvent tomber sur des substances inflammables.
- Se protéger et d'autres personnes de la projection d'étincelles et de métal chaud.
- Des étincelles et des matériaux chauds du soudage peuvent facilement passer dans d'autres zones en traversant de petites fissures et des ouvertures.
- Surveiller tout déclenchement d'incendie et tenir un extincteur à proximité.
- Le soudage effectué sur un plafond, plancher, paroi ou séparation peut déclencher un incendie de l'autre côté.
- Ne pas couper ou souder des jantes ou des roues. Les pneus peuvent exploser s'ils sont chauffés. Les jantes et les roues réparées peuvent défailir. Voir OSHA 29 CFR 1910.177 énuméré dans les normes de sécurité.
- Ne pas effectuer le soudage sur des conteneurs fermés tels que des réservoirs, tambours, ou conduites, à moins qu'ils n'aient été préparés correctement conformément à AWS F4.1 et AWS A6.0 (voir les Normes de Sécurité).
- Ne pas souder là où l'air ambiant pourrait contenir des poussières, gaz ou émanations inflammables (vapeur d'essence, par exemple).
- Brancher le câble de masse sur la pièce la plus près possible de la zone de soudage pour éviter le transport du courant sur une longue distance par des chemins inconnus éventuels en provoquant des risques d'électrocution, d'étincelles et d'incendie.
- Ne pas utiliser le poste de soudage pour dégeler des conduites gelées.
- En cas de non utilisation, enlever la baguette d'électrode du porte-électrode ou couper le fil à la pointe de contact.
- Porter un équipement de protection pour le corps fait d'un matériau résistant et ignifuge (cuir, coton robuste, laine). La protection du corps comporte des vêtements sans huile comme par ex. des gants de cuir, une chemise solide, des pantalons sans revers, des chaussures hautes et une casquette.
- Avant de souder, retirer toute substance combustible de vos poches telles qu'un allumeur au butane ou des allumettes.
- Une fois le travail achevé, assurez-vous qu'il ne reste aucune trace d'étincelles incandescentes ni de flammes.
- Utiliser exclusivement des fusibles ou coupe-circuits appropriés. Ne pas augmenter leur puissance; ne pas les ponter.
- Suivre les recommandations dans OSHA 1910.252(a)(2)(iv) et NFPA 51B pour les travaux à chaud et avoir de la surveillance et un extincteur à proximité.
- Lire et comprendre les fiches de données de sécurité et les instructions du fabricant concernant les adhésifs, les revêtements, les nettoyants, les consommables, les produits de refroidissement, les dégraissateurs, les flux et les métaux.



### DES PIÈCES DE METAL ou DES SALETES peuvent provoquer des blessures dans les yeux.

- Le soudage, l'écaillage, le passage de la pièce à la brosse en fil de fer, et le meulage génèrent des étincelles et des particules métalliques volantes. Pendant la période de refroidissement des soudures, elles risquent de projeter du laitier.
- Porter des lunettes de sécurité avec écrans latéraux ou un écran facial.




### LES ACCUMULATIONS DE GAZ risquent de provoquer des blessures ou même la mort.

- Fermer l'alimentation du gaz comprimé en cas de non utilisation.
- Veiller toujours à bien aérer les espaces confinés ou se servir d'un respirateur d'adduction d'air homologué.



### Les CHAMPS ÉLECTROMAGNÉTIQUES (CEM) peuvent affecter les implants médicaux.


- Les porteurs de stimulateurs cardiaques et autres implants médicaux doivent rester à distance.
- Les porteurs d'implants médicaux doivent consulter leur médecin et le fabricant du dispositif avant de s'approcher de la zone où se déroule du soudage à l'arc, du soudage par points, du gougeage, de la découpe plasma ou une opération de chauffage par induction.



### LE BRUIT peut endommager l'ouïe.

Le bruit des processus et des équipements peut affecter l'ouïe.

- Porter des protections approuvées pour les oreilles si le niveau sonore est trop élevé.



### LES BOUTEILLES peuvent exploser si elles sont endommagées.

Les bouteilles de gaz comprimé contiennent du gaz sous haute pression. Si une bouteille est endommagée, elle peut exploser. Du fait que les bouteilles de gaz font normalement partie du procédé de soudage, les manipuler avec précaution.

- Protéger les bouteilles de gaz comprimé d'une chaleur excessive, des chocs mécaniques, des dommages physiques, du laitier, des flammes ouvertes, des étincelles et des arcs.
- Placer les bouteilles debout en les fixant dans un support stationnaire ou dans un porte-bouteilles pour les empêcher de tomber ou de se renverser.
- Tenir les bouteilles éloignées des circuits de soudage ou autres circuits électriques.
- Ne jamais placer une torche de soudage sur une bouteille à gaz.
- Une électrode de soudage ne doit jamais entrer en contact avec une bouteille.
- Ne jamais souder une bouteille pressurisée – risque d'explosion.
- Utiliser seulement des bouteilles de gaz comprimé, régulateurs, tuyaux et raccords convenables pour cette application spécifique; les maintenir ainsi que les éléments associés en bon état.
- Tourner le dos à la sortie de vanne lors de l'ouverture de la vanne de la bouteille. Ne pas se tenir devant ou derrière le régulateur lors de l'ouverture de la vanne.
- Le couvercle du détendeur doit toujours être en place, sauf lorsque la bouteille est utilisée ou qu'elle est reliée pour usage ultérieur.
- Utilisez les équipements corrects, les bonnes procédures et suffisamment de personnes pour soulever, déplacer et transporter les bouteilles.
- Lire et suivre les instructions sur les bouteilles de gaz comprimé, l'équipement connexe et le dépliant P-1 de la CGA (Compressed Gas Association) mentionné dans les principales normes de sécurité.

## 2-3. Symboles de dangers supplémentaires en relation avec l'installation, le fonctionnement et la maintenance




### Risque D'INCENDIE OU D'EXPLOSION.

- Ne pas placer l'appareil sur, au-dessus ou à proximité de surfaces inflammables.
- Ne pas installer l'appareil à proximité de produits inflammables.
- Ne pas surcharger l'installation électrique – s'assurer que l'alimentation est correctement dimensionnée et protégée avant de mettre l'appareil en service.




### LA CHUTE DE L'ÉQUIPEMENT peut provoquer des blessures.

- Utiliser l'anneau de levage uniquement pour soulever l'appareil, NON PAS les chariots, les bouteilles de gaz ou tout autre accessoire.
- Utilisez les procédures correctes et des équipements d'une capacité appropriée pour soulever et supporter l'appareil.
- En utilisant des fourches de levage pour déplacer l'unité, s'assurer que les fourches sont suffisamment longues pour dépasser du côté opposé de l'appareil.
- Tenir l'équipement (câbles et cordons) à distance des véhicules mobiles lors de toute opération en hauteur.
- Suivre les consignes du Manuel des applications pour l'équation de levage NIOSH révisée (Publication N°94-110) lors du levage manuel de pièces ou équipements lourds.




### L'EMPLOI EXCESSIF peut SURCHAUFFER L'ÉQUIPEMENT.

- Prévoir une période de refroidissement ; respecter le cycle opératoire nominal.
- Réduire le courant ou le facteur de marche avant de poursuivre le soudage.
- Ne pas obstruer les passages d'air du poste.



### LES ÉTINCELLES PROJÉTÉES peuvent provoquer des blessures.

- Porter un écran facial pour protéger le visage et les yeux.
- Affûter l'électrode au tungstène uniquement à la meuleuse dotée de protecteurs. Cette manœuvre est à exécuter dans un endroit sûr lorsque l'on porte l'équipement homologué de protection du visage, des mains et du corps.
- Les étincelles risquent de causer un incendie – éloigner toute substance inflammable.



### LES CHARGES ÉLECTROSTATIQUES peuvent endommager les circuits imprimés.

- Établir la connexion avec la barrette de terre avant de manipuler des cartes ou des pièces.
- Utiliser des pochettes et des boîtes antistatiques pour stocker, déplacer ou expédier des cartes de circuits imprimés.




### Les PIÈCES MOBILES peuvent causer des blessures.

- Ne pas s'approcher des organes mobiles.
- Ne pas s'approcher des points de coincement tels que des rouleaux de commande.



### LES FILS DE SOUDAGE peuvent provoquer des blessures.

- Ne pas appuyer sur la gâchette avant d'en avoir reçu l'instruction.
- Ne pas diriger le pistolet vers soi, d'autres personnes ou toute pièce mécanique en engageant le fil de soudage.




### L'EXPLOSION DE LA BATTERIE peut provoquer des blessures.

- Ne pas utiliser l'appareil de soudage pour charger des batteries ou faire démarrer des véhicules à l'aide de câbles de démarrage, sauf si l'appareil dispose d'une fonctionnalité de charge de batterie destinée à cet usage.



### Les PIÈCES MOBILES peuvent causer des blessures.


- S'abstenir de toucher des organes mobiles tels que des ventilateurs.
- Maintenir fermés et verrouillés les portes, panneaux, recouvrements et dispositifs de protection.
- Lorsque cela est nécessaire pour des travaux d'entretien et de dépannage, faire retirer les portes, panneaux, recouvrements ou dispositifs de protection uniquement par du personnel qualifié.
- Remettre les portes, panneaux, recouvrements ou dispositifs de protection quand l'entretien est terminé et avant de rebrancher l'alimentation électrique.



### LIRE LES INSTRUCTIONS.

- Lire et appliquer les instructions sur les étiquettes et le Mode d'emploi avant l'installation, l'utilisation ou l'entretien de l'appareil. Lire les informations de sécurité au début du manuel et dans chaque section.

- N'utiliser que les pièces de rechange recommandées par le constructeur.
- Effectuer l'installation, l'entretien et toute intervention selon les manuels d'utilisateurs, les normes nationales, provinciales et de l'industrie, ainsi que les codes municipaux.



### LE RAYONNEMENT HAUTE FRÉQUENCE (H.F.) risque de provoquer des interférences.

- Le rayonnement haute fréquence (H.F.) peut provoquer des interférences avec les équipements de radio-navigation et de communication, les services de sécurité et les ordinateurs.
- Demander seulement à des personnes qualifiées familiarisées avec des équipements électroniques de faire fonctionner l'installation.
- L'utilisateur est tenu de faire corriger rapidement par un électricien qualifié les interférences résultant de l'installation.
- Si le FCC signale des interférences, arrêter immédiatement l'appareil.

- Effectuer régulièrement le contrôle et l'entretien de l'installation.
- Maintenir soigneusement fermés les portes et les panneaux des sources de haute fréquence, maintenir les éclateurs à une distance correcte et utiliser une terre et un blindage pour réduire les interférences éventuelles.



### LE SOUDAGE À L'ARC risque de provoquer des interférences.

- L'énergie électromagnétique risque de provoquer des interférences pour l'équipement électronique sensible tel que les ordinateurs et l'équipement commandé par ordinateur tel que les robots.
- Veiller à ce que tout l'équipement de la zone de soudage soit compatible électromagnétiquement.
- Pour réduire la possibilité d'interférence, maintenir les câbles de soudage aussi courts que possible, les grouper, et les poser aussi bas que possible (ex. par terre).
- Veiller à souder à une distance de 100 mètres de tout équipement électronique sensible.
- Veiller à ce que ce poste de soudage soit posé et mis à la terre conformément à ce mode d'emploi.
- En cas d'interférences après avoir pris les mesures précédentes, il incombe à l'utilisateur de prendre des mesures supplémentaires telles que le déplacement du poste, l'utilisation de câbles blindés, l'utilisation de filtres de ligne ou la pose de protecteurs dans la zone de travail.

## 2-4. Proposition californienne 65 Avertissements

**⚠ AVERTISSEMENT : ce produit peut vous exposer à des produits chimiques tels que le plomb, reconnus par l'État de Californie comme cancérigènes et sources de malformations ou d'autres troubles de la reproduction.**

Pour plus d'informations, consulter [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov).

## 2-5. Principales normes de sécurité

*Safety in Welding, Cutting, and Allied Processes*, American Welding Society standard ANSI Standard Z49.1. Website: [www.aws.org](http://www.aws.org).

*Safe Practice For Occupational And Educational Eye And Face Protection*, ANSI Standard Z87.1 from American National Standards Institute. Website: [www.ansi.org](http://www.ansi.org).

*Safe Practices for the Preparation of Containers and Piping for Welding and Cutting*, American Welding Society Standard AWS F4.1 from Global Engineering Documents. Website: [www.global.ihs.com](http://www.global.ihs.com).

*Safe Practices for Welding and Cutting Containers that have Held Combustibles*, American Welding Society Standard AWS A6.0 from Global Engineering Documents. Website: [www.global.ihs.com](http://www.global.ihs.com).

*National Electrical Code*, NFPA Standard 70 from National Fire Protection Association. Website: [www.nfpa.org](http://www.nfpa.org) and [www.sparky.org](http://www.sparky.org).

*Safe Handling of Compressed Gases in Cylinders*, CGA Pamphlet P-1 from Compressed Gas Association. Website: [www.cganet.com](http://www.cganet.com).

*Safety in Welding, Cutting, and Allied Processes*, CSA Standard W117.2 from Canadian Standards Association. Website: [www.csagroup.org](http://www.csagroup.org).

*Standard for Fire Prevention During Welding, Cutting, and Other Hot Work*, NFPA Standard 51B from National Fire Protection Association. Website: [www.nfpa.org](http://www.nfpa.org).

OSHA *Occupational Safety and Health Standards for General Industry*, Title 29, Code of Federal Regulations (CFR), Part 1910.177 Subpart N, Part 1910 Subpart Q, and Part 1926, Subpart J. Website: [www.osha.gov](http://www.osha.gov).

OSHA *Important Note Regarding the ACGIH TLV, Policy Statement on the Uses of TLVs and BEIs*. Website: [www.osha.gov](http://www.osha.gov).

*Applications Manual for the Revised NIOSH Lifting Equation* from the National Institute for Occupational Safety and Health (NIOSH). Website: [www.cdc.gov/NIOSH](http://www.cdc.gov/NIOSH).

## 2-6. Informations relatives aux CEM

Le courant électrique qui traverse tout conducteur génère des champs électromagnétiques (CEM) à certains endroits. Le courant issu d'un soudage à l'arc (et de procédés connexes, y compris le soudage par points, le gougeage, le découpage plasma et les opérations de chauffage par induction) crée un champ électromagnétique (CEM) autour du circuit de soudage. Les champs électromagnétiques produits peuvent causer interférence à certains implants médicaux, p. ex. les stimulateurs cardiaques. Des mesures de protection pour les porteurs d'implants médicaux doivent être prises: Limiter par exemple tout accès aux passants ou procéder à une évaluation des risques individuels pour les soudeurs. Tous les soudeurs doivent appliquer les procédures suivantes pour minimiser l'exposition aux CEM provenant du circuit de soudage:

1. Rassembler les câbles en les torsadant ou en les attachant avec du ruban adhésif ou avec une housse.
2. Ne pas se tenir au milieu des câbles de soudage. Disposer les

câbles d'un côté et à distance de l'opérateur.

3. Ne pas courber et ne pas entourer les câbles autour de votre corps.
4. Maintenir la tête et le torse aussi loin que possible du matériel du circuit de soudage.
5. Connecter la pince sur la pièce aussi près que possible de la soudure.
6. Ne pas travailler à proximité d'une source de soudage, ni s'asseoir ou se pencher dessus.
7. Ne pas souder tout en portant la source de soudage ou le dévidoir.

### En ce qui concerne les implants médicaux :

Les porteurs d'implants doivent d'abord consulter leur médecin avant de s'approcher des opérations de soudage à l'arc, de soudage par points, de gougeage, du coupage plasma ou de chauffage par induction. Si le médecin approuve, il est recommandé de suivre les procédures précédentes.





## SECTION 4 – SPECIFICATIONS

### 4-1. Serial Number And Rating Label Location

The serial number and rating information for this product is located on the back of unit. Use rating label to determine input power requirements and/or rated output. For future reference, write serial number in space provided on back cover of this manual.

### 4-2. Software Licensing Agreement

The End User License Agreement and any third-party notices and terms and conditions pertaining to third-party software can be found at <https://www.hobartwelders.com/eula>. and are incorporated by reference herein.

### 4-3. Information About Default Weld Parameters And Settings

**NOTICE** – Each welding application is unique. Although certain Miller Electric products are designed to determine and default to certain typical welding parameters and settings based upon specific and relatively limited application variables input by the end user, such default settings are for reference purposes only; and final weld results can be affected by other variables and application-specific circumstances. The appropriateness of all parameters and settings should be evaluated and modified by the end user as necessary based upon application-specific requirements. The end user is solely responsible for selection and coordination of appropriate equipment, adoption or adjustment of default weld parameters and settings, and ultimate quality and durability of all resultant welds. Miller Electric expressly disclaims any and all implied warranties including any implied warranty of fitness for a particular purpose.

### 4-4. Unit Specifications For MIG (GMAW)

☞ Do not use information in unit specifications table to determine electrical service requirements. See Sections 5-3, 5-5, and 5-6 for information on connecting input power.

Input Voltage	Rated Welding Output	Amperage Range	Maximum Open-Circuit Voltage DC	Amperes Input at Rated Load Output, 50/60 Hz, Single-Phase
120 VAC	100 A @ 19.0 Volts DC 40% Duty Cycle	30 – 120	63	20.9
	<b>Wire Type And Diameter</b>	<b>Solid/Stainless</b>	<b>Flux Cored</b>	<b>Wire Feed Speed Range</b>
		.024 - .035 in. (0.6 - 0.8 mm)	.030 - .035 in. (0.8 - 0.9 mm)	60 – 650 IPM (1.5 – 16.5 m/min)
240 VAC	200 A @ 24.0 Volts DC 15% Duty Cycle	30 – 200	63	25.0
	140 A @ 21.0 Volts DC 40% Duty Cycle			25.1
	<b>Wire Type And Diameter</b>	<b>Solid/Stainless</b>	<b>Flux Cored</b>	<b>Wire Feed Speed Range</b>
		.024 – .035 in. (0.6 – 0.9 mm)	.030 – .045 in. (0.8 – 1.2 mm)	60 – 650 IPM (1.5 – 16.5 m/min)

### 4-5. Unit Specifications For TIG (GTAW)

☞ Do not use information in unit specifications table to determine electrical service requirements. See Sections 5-3, 5-5, and 5-6 for information on connecting input power.

Input Voltage	Rated Welding Output	Amperage Range	Maximum Open-Circuit Voltage DC	Amperes Input at Rated DC Load Output, 50/60 Hz, Single-Phase
120 VAC	140 A @ 15.6 Volts AC/DC 20% Duty Cycle	20 – 140	63	25.0
240 VAC	200 A @ 18.0 Volts AC/DC 20% Duty Cycle	20 – 200	63	20.0

### 4-6. Unit Specifications For Stick (SMAW)

☞ Do not use information in unit specifications table to determine electrical service requirements. See Sections 5-3, 5-5, and 5-6 for information on connecting input power.

Input Voltage	Rated Welding Output	Amperage Range	Maximum Open-Circuit Voltage DC	Amperes Input at Rated DC Load Output, 50/60 Hz, Single-Phase
120 VAC	80 A @ 23.2 Volts AC/DC 40% Duty Cycle	30 – 100	63	19.2
240 VAC	170 A @ 28.0 Volts AC/DC 15% Duty Cycle	30 – 200	63	23.5

## 4-7. Environmental Specifications

### A. IP Rating

IP Rating
IP21S
This equipment is designed for indoor use and is not intended to be used or stored outside.
IP21S 2014-06


### B. Temperature Specifications

Operating Temperature Range*	Storage/Transportation Temperature Range
14 to 104°F (-10 to 40°C)	-4 to 131°F (-20 to 55°C)
*Output is degraded at temperatures above 104°F (40°C).	Temp_2016-07

## 4-8. Dimensions And Weight



**Weight**  
38.4 lb (17.4 kg)



10.60 in.  
(270 mm)

13.40 in.  
(340 mm)

20.80 in.  
(530 mm)

Ref. 500578-A


### 4-9. Duty Cycle And Overheating For MIG (GMAW)



Duty Cycle is percentage of 10 minutes that unit can weld at rated load without overheating.


If unit overheats, output stops. Wait fifteen minutes for unit to cool. Reduce amperage or duty cycle before starting to weld again.

**NOTICE** – Exceeding duty cycle can damage unit and void warranty.



120V Input


60% Duty Cycle At 80A




240V Input

20% Duty Cycle At 185A

40% Duty Cycle At 145A



Overheating




## 4-10. Duty Cycle And Overheating For TIG (GTAW)



Duty Cycle is percentage of 10 minutes that unit can weld at rated load without overheating.


If unit overheats, output stops. Wait fifteen minutes for unit to cool. Reduce amperage or duty cycle before starting to weld again.

**NOTICE** – Exceeding duty cycle can damage unit and void warranty.




120V Input

40% Duty Cycle At 95A




240V Input

20% Duty Cycle At 200A



Overheating



duty1 4/95 – Ref. Duty Cycle Charts


## 4-11. Duty Cycle And Overheating For Stick (SMAW)



Duty Cycle is percentage of 10 minutes that unit can weld at rated load without overheating.


If unit overheats, output stops. Wait fifteen minutes for unit to cool. Reduce amperage or duty cycle before starting to weld again.

**NOTICE** – Exceeding duty cycle can damage unit and void warranty.




120V Input

40% Duty Cycle At 80A




240V Input

20% Duty Cycle At 170A



Overheating




# SECTION 5 – INSTALLATION

## 5-1. Selecting A Location




**⚠ Do not move or operate unit where it could tip.**

### Movement




### Location And Airflow




**⚠ Special installation may be required where gasoline or volatile liquids are present – see NEC Article 511 or CEC Section 20.**

- 1 Lifting Handle  
Use handle to lift unit.
- 2 Line Disconnect Device  
Locate unit near correct input power supply.



## 5-2. Multi-Voltage Plug (MVP) Connection



### Selecting Plug

- 1 Power Cord Connector From Welding Power Source

Select plug for power supply receptacle available at site. Not all plugs shown are provided as standard with unit.

- 2 Plug – NEMA Type 5–15P
- 3 Receptacle – NEMA Type 5–15R (Customer Supplied)

- 4 Plug – NEMA Type 5–20P (Optional)
- 5 Receptacle – NEMA Type 5–20R (Customer Supplied)
- 6 Plug – NEMA Type 6–50P
- 7 Receptacle – NEMA Type 6–50R (Customer Supplied)

**⚠ Follow electrical service guide for 240 VAC in Section 5-3. Do not use plug rating to size branch circuit protection.**

### Connecting Plug To Power Cord

Align arrow on plug with arrow on power cord connector. Push together.

Tighten threaded collar. As threaded collar is tightened, push plug onto adapter until collar is completely tight.

Connect plug to receptacle.

### 5-3. Electrical Service Guide

**⚠** Failure to follow these electrical service guide recommendations could create an electric shock or fire hazard. These recommendations are for an individual branch circuit sized for the rated output and duty cycle of one welding power source.

In individual branch circuit installations, the National Electrical Code (NEC) allows the receptacle or conductor rating to be less than the rating of the circuit protection device. All components of the circuit must be physically compatible. See NEC articles 210.21, 630.11, and 630.12.

	50/60 Hz 1-Phase	50/60 Hz 1-Phase
<b>Rated Supply Voltage (V)</b>	120	240
<b>Rated Maximum Supply Current <math>I_{1max}</math> (A)</b>	A 15 or 20 ampere individual branch circuit protected by time-delay fuses or circuit breaker is required. See Section 5-5.	32
<b>Maximum Effective Supply Current <math>I_{1eff}</math> (A)</b>		15
<b>Maximum Recommended Standard Fuse Rating In Amperes <sup>1</sup></b> <b>Time-Delay Fuses <sup>2</sup></b> <b>Normal Operating Fuses <sup>3</sup></b>		40
		45
<b>Maximum Recommended Supply Conductor Length In Feet (Meters) <sup>4</sup></b>		34 (10)
<b>Raceway Installation</b>		
<b>Minimum Supply Conductor Size In AWG (mm<sup>2</sup>) <sup>5</sup></b>		12
<b>Minimum Grounding Conductor Size In AWG (mm<sup>2</sup>) <sup>5</sup></b>	12	

Reference: 2020 National Electrical Code (NEC) (including article 630)

- 1 If a circuit breaker is used in place of a fuse, choose a circuit breaker with time-current curves comparable to the recommended fuse.
- 2 "Time-Delay" fuses are UL class "RK5" . See UL 248.
- 3 "Normal Operating" (general purpose - no intentional delay) fuses are UL class "K5" (up to and including 60 amps), and UL class "H" ( 65 amps and above).
- 4 Maximum total length of copper input conductors in entire installation, raceway and/or flexible cord.
- 5 Raceway conductor data in this section specifies conductor size (excluding flexible cord or cable) between the panelboard and the equipment per NEC Table 310.15(B)(16) and is based on allowable ampacities of insulated copper conductors having a temperature rating of 75°C (167°F) with not more than three single current-carrying conductors in a raceway.

### 5-4. Input Power Extension Cord Data

**⚠** Use extension cord only for temporary wiring. Remove extension cord immediately after completing the project.

Input 17 2018-11

Cord Type	Minimum Conductor Size	Number of Conductors	Maximum Cord Length
Heavy Duty (Hard Usage)	12 AWG (4 mm <sup>2</sup> )	3	50 ft (15 m)

 Read OSHA Standard 1910.334 for more information on the use of cord and plug connected equipment.  
Read National Electrical Code (NEC) Article 590 for more information on temporary wiring.

## 5-5. Connecting 120 Volt Input Power



**⚠ Installation must meet all National and Local Codes – have only qualified persons make this installation.**

**⚠ Special installation may be required where gasoline or volatile liquids are present – see NEC Article 511 or CEC Section 20.**


See rating label on unit and check input voltage available at site.

For 120 volts AC input power, a 15 or 20 ampere individual branch circuit protected by time-delay fuses or circuit breaker is required.

- 1 Multi-Voltage Plug And Power Cord Connector (NEMA Type 5-15P Plug Shown)

For multi-voltage plug connections, see Section 5-2.




- 2 Receptacle – NEMA Type 5-15R (Customer Supplied)



## 5-6. Connecting 1-Phase Input Power For 240 VAC



Tools Needed:



**⚠** Installation must meet all National and Local Codes – have only qualified persons make this installation.

**⚠** Disconnect and lockout/tagout input power before connecting input conductors from unit. Follow established procedures regarding the installation and removal of lockout/tagout devices.

**⚠** Always connect green or green/yellow conductor to supply grounding terminal first, and never to a line terminal.

See rating label on unit and check input voltage available at site.

- 1 Input Power Cord
- 2 Disconnect Device (switch shown in the OFF position).
- 3 Disconnect Device Grounding Terminal
- 4 Disconnect Line Terminal
- 5 Black and White Input Conductor (L1 and L2)
- 6 Green or Green/Yellow Grounding Conductor.

Connect green or green/yellow grounding conductor to disconnect device grounding terminal first.

Connect input conductors L1 and L2 to disconnect device line terminals.

7 Over Current Protection

Select type and size of over-current protection using Section 5-3 (fused disconnect switch shown).

8 Receptacle (NEMA 6-50R)  
Customer Supplied

Close and secure door on disconnect device. Remove lockout/tagout device, and place switch in the On position.



## 5-8. Stick Welding Connections



**!** Turn off unit and disconnect input power before making connections.


**!** Do not use worn, damaged, undersized, or repaired cables.

- 1 Negative (-) Weld Output Terminal
- 2 Positive (+) Weld Output Terminal
- 3 Stick Electrode Holder And Cable
- 4 Work Clamp And Cable

Insert connectors fully into terminals. Rotate connector clockwise to lock in position.

Consult stick electrode manufacturer's guidelines for proper polarity and best results.

**Ensure all connections are tight.**



## 5-9. TIG Welding Connections



**⚠ Turn off unit and disconnect input power before making connections.**

**⚠ Do not use worn, damaged, undersized, or repaired cables.**

- 1 Negative (-) Weld Output Terminal
- 2 Positive (+) Weld Output Terminal
- 3 TIG Torch And Cable
- 4 Work Clamp And Cable

Connect TIG torch cable to the negative receptacle and connect work cable to the positive receptacle. Turn connectors clockwise.


**Ensure all connections are tight.**

- 5 Optional Foot Control with RJ-45 connector
- 6 RJ-45 Remote Control Receptacle

Connect foot control to remote control receptacle.

- 7 TIG Shielding Gas Connection

Use Argon gas for TIG welding (see Section 5-13).




Tools Needed:




## 5-10. Process/Polarity Table

Process	Polarity	Cable Connections	
		Wire Drive Assembly Cable	Work Cable
GMAW – Solid wire with shielding gas	DCEP – Reverse polarity	Connect to positive (+) output receptacle	Connect to negative (-) output receptacle
FCAW – Self-shielding wire – no shielding gas	DCEN – Straight Polarity	Connect to negative (-) output receptacle	Connect to positive (+) output receptacle


## 5-11. MIG Welding Connections



**MIG – DCEP**  
(Direct Current Electrode Positive)



**Flux-Cored – DCEN**  
(Direct Current Electrode Negative)



Tools Needed:



Ref. 287758-A / Ref. 275167A / Ref. 275168A

**⚠ Turn off unit and disconnect input power before making connections.**

- 1 Positive Weld Output Receptacle
- 2 Negative Weld Output Receptacle
- 3 Wire Drive Assembly Cable
- 4 Work Clamp And Cable

**Ensure all connections are tight.**


- 5 Gun End
- Connect gun end to drive assembly (see Section 5-12).
- 6 Trigger Control Cable
- 7 Four Pin Trigger Control Cable Receptacle

Connect plug on end of cable to four pin receptacle on front of unit.

- 8 MIG Shielding Gas Connection

Use 75/25 mix or CO<sub>2</sub> shielding gas for solid wire. Use Argon shielding gas for aluminum wire with spool gun (see Section 5-13).

## 5-12. MIG Gun Connection Inside Unit



Make sure that gun end is tight against drive assembly.

- 1 Gun Securing Knob
- 2 Gun Block
- 3 Gun Outlet Wire Guide
- 4 Gun End



Loosen knob. Insert end of gun through opening in front panel until gun end bottoms against gun block. Tighten knob.

- 5 O-Ring


If o-ring is visible, the MIG gun is not inserted fully.

- 6 Trigger Control Cable
- 7 Four Pin Trigger Control Cable Connection

Connect plug on end of cable to four pin receptacle on front of unit.



## 5-13. Connecting Shielding Gas Supply



Obtain gas cylinder and chain to running gear, wall, or other stationary support so cylinder cannot fall and break off valve.

- 1 Cap
- 2 Cylinder Valve

Remove cap, stand to side of valve, and open valve slightly. Gas flow blows dust and dirt from valve. Close valve.

- 3 Cylinder
- 4 Regulator/Flowmeter

Install Regulator/Flowmeter so face is vertical.

- 5 Regulator/Flowmeter Gas Hose Connection
- 6 Welding Power Source CO<sub>2</sub> And Mixed Gas (MIG) Hose Connection or Argon (TIG) or (Spool gun) hose connection.

Connect gas hose between regulator/flowmeter gas hose connection for gas type being used, and the fitting on rear of welding power source. Only one gas hose can be attached at a time.

- 7 Flow Adjust

Typical flow rate for CO<sub>2</sub> shielding gas and MIG (GMAW) welding is 15 to 30 CFH (cubic feet per hour) (7.05 - 14.1 LPM) and mixed gas is 25 to 45 CFH (11.75 - 21.15LPM).

Typical flow rate for Argon shielding gas and TIG (GTAW) welding is 15 to 25 CFH (7.05 - 11.75LPM) and aluminum MIG (GMAW) welding is 35 to 45 CFH (16.45 - 21.15 LPM). Check wire manufacturer's recommended flow rate.

- 8 CO<sub>2</sub> Adapter (Customer Supplied)

- 9 O-Ring (Customer Supplied)

Install adapter with O-ring between regulator/flowmeter and CO<sub>2</sub> cylinder.


Tools Needed:




## 5-14. Installing Wire Spool And Adjusting Hub Tension




- 1 Retaining Nut – For 8 in. (203 mm) Spool Only
- 2 4 in. Wire Spool
- 3 8 in. Wire Spool




### Installing 4 in. (102 mm) Wire Spool




When a slight force is needed to turn spool, tension is set.



### Installing 8 in. (203 mm) Wire Spool



When a slight force is needed to turn spool, tension is set.



Tools Needed:



1/2 in.



## 5-15. Threading Welding Wire



Tools Needed:



- 1 Wire Spool
  - 2 Welding Wire
  - 3 Inlet Wire Guide
  - 4 Pressure Adjustment Knob
  - 5 Drive Roll
  - 6 Gun Input Liner
  - 7 Gun Conduit Cable
- Lay gun cable out straight.




☞ Hold wire tightly to keep it from unraveling.

Open pressure assembly.

Pull and hold wire; cut off end.

Push wire through guides into gun; continue to hold wire.



☞ Use pressure indicator scale to set a desired drive roll pressure. Begin with a setting of 2. If necessary, make additional adjustments after trying this initial setting.


Tighten

Pressure Indicator Scale

Close and tighten pressure assembly, and let go of wire.

Remove gun nozzle and contact tip.

Turn On.




Press gun trigger until wire comes out of gun. Reinstall contact tip and nozzle


Feed wire to check drive roll pressure. Tighten knob enough to prevent slipping.

Cut off wire. Close and latch door.


### 5-16. Removing MIG Gun To Replace With A Spool Gun



Turn Off Power.




Cut Off End Of Wire.




Open Pressure Assembly.


Hold wire tightly to keep it from unraveling.




Rewind Wire Onto Spool, Fasten End Of Wire To Spool.




Knob



Loosen Knob, Disconnect Gun Trigger Plug, And Remove Gun From Unit.



Insert Power Pin, Connect Spool Gun Trigger Plug, And Tighten Knob.






Tools Needed:



# SECTION 6 – OPERATION

## 6-1. Controls



**Rear View**


Ref. 500578-A

- 1 Display
- 2 Voltage Control Knob  
Controls voltage in MIG process. See weld parameter chart for initial setting.
- 3 MIG Gun and Spool Gun Trigger Receptacle
- 4 MIG Gun and Spool Gun Power Receptacle

- 5 Positive Output Receptacle
- 6 Negative Output Receptacle
- 7 TIG Remote Receptacle  
Connect optional foot control to unit.
- 8 Process Select Button  
Press the button to select the desired process.


- 9 Wire Feed/Amperage Knob  
Controls wire feed speed in MIG process and amperage in the stick or TIG process. See weld parameter chart for initial settings.
- 10 Power Switch
- 11 Shielding Gas Fitting
- 12 Circuit Breaker CB1

## 6-2. Screen, Power-Up Mode




- 1 Power Switch  
Push toggle to ON position.
- 2 Display

Three seconds into the power up process, the screen will display the input voltage (either 120V or 240V).




Ref. 287758-A

## 6-3. Screen, Wire Jog Mode






- 1 Display  
Jog mode is displayed when feeding wire through the MIG gun.
- 2 Wire Feed Knob  
Jog speed can be adjusted using the wire feed knob while in Jog mode.



Ref. 287758-A

## 6-4. Controls, MIG Mode (Menu 1 Of 5)



### 1 Process Select Button

Push button to enter MIG process. Check weld parameter chart for correct polarity at positive (+) and negative (-) receptacles.

See section 5-11 for proper cable placement.

### 2 Voltage Knob

Adjust voltage knob per weld parameter chart for initial setting.

### 3 Wire Feed Knob

Adjust wire feed knob per weld parameter chart for initial setting.



### 4 Display

### 5 Live Output Signal

 When the symbol is activated on the display the output is on.

The output is on in the MIG process when the trigger on the MIG gun or spoolgun is activated.

## 6-5. Controls, Flux Cored Mode (Menu 2 Of 5)



### 1 Process Select Button

Push button to enter Flux-cored process. Check weld parameter chart for correct polarity at positive (+) and negative (-) receptacles.

See section 5-11 for proper cable placement.

### 2 Voltage Knob

Adjust voltage knob per weld parameter chart for initial setting.

### 3 Wire Feed Knob

Adjust wire feed knob per weld parameter chart for initial setting.



### 4 Display

### 5 Live Output Signal

*When the symbol is activated on the display the output is on.*

The output is on in the Flux-cored process when the trigger on the MIG gun is activated.

## 6-6. Controls, TIG Mode (Menu 3 Of 5)



### 1 Process Select Button

In the TIG process when the optional foot control is not being used, the output is on when the TIG process is selected.

Push button to enter TIG process. Check weld parameter chart for correct polarity at positive (+) and negative (-) receptacles.

See section 5-9 for proper cable placement.

### 2 Amperage Knob

Adjust amperage knob per weld parameter chart for initial setting.

### 3 Display



### 4 Live Output signal

 When the symbol is activated on the display the output is on.

### 5 Voltage Displayed

The voltage is displayed only during welding.

## 6-7. Controls, TIG Mode With Foot Pedal(Menu 4 Of 5)



### 1 Process Select Button

In the TIG process when the optional foot control is being used, the output is controlled by the foot pedal.

Push button to enter TIG process. Check weld parameter chart for correct polarity at positive (+) and negative (-) receptacles.

See section 5-9 for proper cable placement.

### 2 TIG Foot Pedal Connection

### 3 Amperage Knob

Adjust amperage knob per weld parameter chart for initial setting.

### 4 Display



### 5 Live Output signal

When the symbol is activated on the display the output is on.

### 6 Voltage Displayed

The voltage is displayed only during welding.

## 6-8. Controls, Stick Mode (Menu 5 Of 5)



### 1 Process Select Button

Push button to enter Stick process. Check weld parameter chart for correct polarity at positive (+) and negative (-) receptacles.

See section 5-8 for proper cable placement.

### 2 Amperage Knob

Adjust amperage knob per weld parameter chart for initial setting.

### 3 Display

### 4 Live Output signal

 When the symbol is activated on the display the output is on.

The output is always on when the Stick process is selected.

### 5 Voltage Displayed

The voltage is displayed only during welding.



# SECTION 7 – WELD PARAMETER CHARTS

## 7-1. Welding Parameters 120 Volt

MIG/Flux-Cored Welding Parameters							
Material Being Welded	Wire Type and Polarity Setting	Shielding Gas 20-30 cfh Flow Rate	Wire Diameter	120 V			
				24 ga. .024 in. (0.6 mm)	22 ga. .030 in. (0.8 mm)	20 ga. .036 in. (0.9 mm)	18 ga. .048 in. (1.2 mm)
Steel	Solid Wire ER70S-6 DCEP	C25 Mix 75% Argon /25% CO <sub>2</sub>	.024"	14.4/130	14.6/150	15.2/185	16.5/250
			.030"	14.0/94	14.1/109	15.2/120	16.1/157
			.035"	---	---	---	15.7/135
		100% CO <sub>2</sub>	.024"	---	---	---	18.0/230
			.030"	---	---	---	---
			.035"	---	---	---	---
Stainless Steel	Stnls Steel 308L DCEP	98% Ar/2% CO <sub>2</sub>	.030"	---	---	---	15.2/242
			.035"	---	---	---	---
Steel	Flux Core E71T-11 DCEN	Shielding Gas not Required Use Outdoors	.030"	---	---	---	13.1/140
			.035"	---	---	---	13.3/108
			.045"	---	---	---	---
Aluminum* W/Optional SpoolRunner™ 100	4043 AL DCEP	100% Argon	.030"	---	---	---	14.2/304
			.035"	---	---	---	---
	5356 AL DCEP	100% Argon	.030"	---	---	---	13.6/330
			.035"	---	---	---	---

TIG Welding Parameters							
Material Being Welded	Polarity Setting	Shielding Gas 20-30 cfh Flow Rate	Tungsten Diameter	120 V			
				24 ga. (Amps)	22 ga. (Amps)	20 ga. (Amps)	18 ga. (Amps)
Steel, Stainless Stl	DCEN	100% Argon	1/16"	27	30	35	50
			3/32"	27	30	35	50

Stick Welding Parameters							
Material Being Welded	Polarity Setting	Electrode Type	Electrode Diameter	120 V			
				24 ga. (Amps)	22 ga. (Amps)	20 ga. (Amps)	18 ga. (Amps)
Steel	DCEP	6011	3/32"	---	---	---	---
			1/8"	---	---	---	---
			5/32"	---	---	---	---
		6013	3/32"	---	---	---	---
			1/8"	---	---	---	---
			5/32"	---	---	---	---
		7014	3/32"	---	---	---	---
			1/8"	---	---	---	---
			5/32"	---	---	---	---
		7018	3/32"	---	---	---	---
			1/8"	---	---	---	---
			5/32"	---	---	---	---

MIG/Flux-Cored Welding Parameters								
Material Being Welded	Wire Type and Polarity Setting	Shielding Gas 20-30 cfh Flow Rate	Wire Diameter	120 V				
				16 ga. .060 in. (1.6 mm)	14 ga. .075 in. (1.9 mm)	1/8 in. (3.2 mm)	3/16 in. (4.8 mm)	1/4 in. (6.4 mm)
Steel	Solid Wire ER70S-6 DCEP	C25 Mix 75% Argon /25% CO <sub>2</sub>	.024"	17.8/350	19.0/405	21.0/584	---	---
			.030"	17.0/174	17.4/248	19.0/352	---	---
			.035"	15.7/155	16.6/180	18.3/270	---	---
		100% CO <sub>2</sub>	.024"	19.5/349	20.2/440	20.7/480	---	---
			.030"	17.7/183	19.3/215	21.0/260	---	---
			.035"	17.4/142	18.4/185	19.8/226	---	---
Stainless Steel	Stnls Steel 308L DCEP	98% Ar/2% CO <sub>2</sub>	.030"	16.0/264	18.0/334	19.2/400	---	---
			.035"	---	---	---	---	---
Steel	Flux Core E71T-11 DCEN	Shielding Gas not Required Use Outdoors	.030"	14.2/160	17.5/264	19.8/311	21.0/356	---
			.035"	13.5/114	16.3/175	18.5/189	19.3/210	---
			.045"	---	---	---	---	---
Aluminum* W/Optional SpoolRunner™ 100	4043 AL DCEP	100% Argon	.030"	14.9/309	15.6/345	19.3/405	---	---
			.035"	---	---	---	---	---
	5356 AL DCEP	100% Argon	.030"	14.3/350	17.4/463	20.2/650	---	---
			.035"	---	---	---	---	---

TIG Welding Parameters								
Material Being Welded	Polarity Setting	Shielding Gas 20-30 cfh Flow Rate	Tungsten Diameter	120 V				
				16 ga. (Amps)	14 ga. (Amps)	1/8 in. (Amps)	3/16 in. (Amps)	1/4 in. (Amps)
Steel, Stainless Stl	DCEN	100% Argon	1/16"	60	75	125	137	---
			3/32"	60	75	125	137	---

Stick Welding Parameters								
Material Being Welded	Polarity Setting	Electrode Type	Electrode Diameter	120 V				
				16 ga. (Amps)	14 ga. (Amps)	1/8 in. (Amps)	3/16 in. (Amps)	1/4 in. (Amps)
Steel	DCEP	6011	3/32"	40	45	60	85	---
			1/8"	---	60	75	85	95
			5/32"	---	---	---	---	---
		6013	3/32"	45	65	70	85	---
			1/8"	---	60	85	90	95
			5/32"	---	---	---	---	---
		7014	3/32"	60	70	85	90	---
			1/8"	60	70	85	90	100
			5/32"	---	---	---	---	---
		7018	3/32"	60	70	85	90	---
			1/8"	---	---	90	95	---
			5/32"	---	---	---	---	---

## 7-2. Welding Parameters 240 Volt

MIG/Flux-Cored Welding Parameters									
Material Being Welded	Wire Type and Polarity Setting	Shielding Gas 20-30 cfh Flow Rate	Wire Diameter	240 V					
				24 ga. .024 in. (0.6 mm)	22 ga. .030 in. (0.8 mm)	20 ga. .036 in. (0.9 mm)	18 ga. .048 in. (1.2 mm)	16 ga. .060 in. (1.6 mm)	14 ga. .075 in. (1.9 mm)
Steel	Solid Wire ER70S-6 DCEP	C25 Mix 75%Argon /25% CO <sub>2</sub>	.024"	14.3/137	14.6/165	15.2/210	16.3/300	18.0/400	19.3/460
			.030"	14.0/100	14.1/105	15.2/120	16.1/157	17.0/174	17.4/248
			.035"	--	--	--	15.1/130	15.3/154	16.4/160
		100% CO <sub>2</sub>	.024"	--	--	--	17.3/230	17.6/239	18.2/378
			.030"	--	--	--	17.2/149	17.7/183	19.3/215
			.035"	--	--	--	17.0/113	17.2/146	18.4/170
Stainless Steel	Stnls Steel 308L DCEP	98% Ar/2% CO <sub>2</sub>	.030"	--	--	--	15.3/242	16.6/295	17.3/370
			.035"	--	--	--	--	15.5/235	16.2/265
Steel	Flux Core E71T-11 DCEN	Shielding Gas not Required Use Outdoors	.030"	--	--	--	13.1/140	16.5/235	17.5/306
			.035"	--	--	--	14.0/94	15.0/110	16.0/130
			.045"	--	--	--	--	14.0/90	14.2/112
Aluminum* W/ Optional Spoolrunner™ 100	4043 AL DCEP	100% Argon	.030"	--	--	--	13.0/230	14.9/309	16.0/355
			.035"	--	--	--	--	--	--
	5356 AL DCEP	100% Argon	.030"	--	--	--	13.6/330	14.3/350	17.4/463
			.035"	--	--	--	--	--	--

TIG Welding Parameters									
Material Being Welded	Polarity Setting	Shielding Gas 20-30 cfh Flow Rate	Tungsten Diameter	240 V					
				24 ga. (Amps)	22 ga. (Amps)	20 ga. (Amps)	18 ga. (Amps)	16 ga. (Amps)	14 ga. (Amps)
Steel, Stainless Stl	DCEN	100% Argon	1/16"	27	30	35	50	60	75
			3/32"	27	30	35	50	60	75

Stick Welding Parameters									
Material Being Welded	Polarity Setting	Electrode Type	Electrode Diameter	240 V					
				24 ga. (Amps)	22 ga. (Amps)	20 ga. (Amps)	18 ga. (Amps)	16 ga. (Amps)	14 ga. (Amps)
Steel	DCEP	6011	3/32"	--	--	--	--	42	45
			1/8"	--	--	--	--	--	60
			5/32"	--	--	--	--	--	--
		6013	3/32"	--	--	--	--	45	65
			1/8"	--	--	--	--	--	60
			5/32"	--	--	--	--	--	--
		7014	3/32"	--	--	--	--	50	70
			1/8"	--	--	--	--	--	--
			5/32"	--	--	--	--	--	--
		7018	3/32"	--	--	--	--	65	70
			1/8"	--	--	--	--	--	--
			5/32"	--	--	--	--	--	--

Ref. 287984-B

MIG/Flux-Cored Welding Parameters								
Material Being Welded	Wire Type and Polarity Setting	Shielding Gas 20-30 cfh Flow Rate	Wire Diameter	240 V				
				1/8 in. (3.2 mm)	3/16 in. (4.8 mm)	1/4 in. (6.4 mm)	5/16 in. (7.9 mm)	3/8 in. (9.5 mm)
Steel	Solid Wire ER70S-6 DCEP	75% Argon /25% CO <sub>2</sub> Less Spatter	.024"	20.3/494	22.0/650	22.3/650	---	---
			.030"	18.5/318	20.8/420	21.7/486	23.0/535	23.7/600
			.035"	17.5/246	18.5/280	19.0/305	20.0/360	20.5/375
		100% CO <sub>2</sub>	.024"	22.3/555	24.7/650	---	---	---
			.030"	20.2/290	21.9/368	22.6/381	23.0/475	25.7/530
			.035"	19.3/241	21.0/290	21.7/330	24.0/412	24.0/418
Stainless Steel	Stnls Steel 308L DCEP	98% Ar/2% CO <sub>2</sub>	.030"	18.3/410	20.2/505	24.0/505	24.8/560	25.6/580
			.035"	18.8/355	19.5/415	24.6/440	25.0/450	25.1/455
Steel	Flux Core E71T-11 DCEN	Shielding Gas not Required Use Outdoors	.030"	19.8/362	20.7/395	21.1/404	---	---
			.035"	18.5/189	20.4/238	21.7/275	23.2/300	23.4/370
			.045"	14.9/137	19.0/170	19.6/200	20.0/205	20.1/220
Aluminum* with Optional SpoolRunner™ 100	4043 AL DCEP	100% Argon	.030"	19.3/422	23.0/525	---	---	---
			.035"	19.4/346	22.2/414	---	---	---
	5356 AL DCEP	100% Argon	.030"	20.2/650	---	---	---	---
			.035"	19.5/485	21.0/650	---	---	---


TIG Welding Parameters								
Material Being Welded	Polarity Setting	Shielding Gas 20-30 cfh Flow Rate	Tungsten Diameter	240 V				
				1/8 in. (Amps)	3/16 in. (Amps)	1/4 in. (Amps)	5/16 in. (Amps)	3/8 in. (Amps)
Steel, Stainless Stl	DCEN	100% Argon	1/16"	125	137	---	---	---
			3/32"	125	137	175	---	---


Stick Welding Parameters								
Material Being Welded	Polarity Setting	Electrode Type	Electrode Diameter	240 V				
				1/8 in. (Amps)	3/16 in. (Amps)	1/4 in. (Amps)	5/16 in. (Amps)	3/8 in. (Amps)
Steel	DCEP	6011	3/32"	60	85	---	---	---
			1/8"	80	90	100	110	---
			5/32"	125	130	145	150	---
		6013	3/32"	70	90	---	---	---
			1/8"	80	95	115	130	155
			5/32"	120	130	150	155	160
		7014	3/32"	85	95	---	---	---
			1/8"	100	110	125	135	140
			5/32"	115	120	145	150	155
		7018	3/32"	85	95	---	---	---
			1/8"	105	115	120	130	135
			5/32"	115	120	140	145	160

# SECTION 8 – MAINTENANCE & TROUBLESHOOTING

## 8-1. Routine Maintenance




**Disconnect power before maintaining.**  *Maintain more often during severe conditions.*

	✓ = Check      ◇ = Change      ● = Clean * To be done by Factory Authorized Service Agent	☆ = Replace	Reference
Every 3 Months	  ☆ Damaged Or Unreadable Labels	 ☆ Repair Or Replace Cracked Weld Cable	
Every 6 Months	 ● Inside Unit	 ● Clean Drive Rolls	

## 8-2. Overload Protection



1 Supplementary Protector CB1  
 CB1 protects unit from overload. If CB1 opens, unit shuts down.  
 Reset supplementary protector.



500578A

### 8-3. Changing Drive Roll Or Wire Inlet Guide



#### 1 Inlet Wire Guide

Remove guide by pressing on barbed area or cutting off one end near housing and pulling it out of hole. Push new guide into hole from rear until it snaps in place.


#### 2 Drive Roll

The drive roll includes three different sized grooves. The text aligned with the drive roll retaining pin indicates the selected groove.

#### 3 Retaining Pin

To secure drive roll, locate open slot and push drive roll completely over retaining pin, then rotate drive roll to desired slot.

See Section 14-2 for optional drive rolls.



**Table 7-1. Drive Roll Grooves And Wire Type Compatibility**

Groove	Compatible Wire
.024	.024 Solid Wire
.030-.035	.030-.035 Solid Wire
.030-.035 V-Knurled	.030-.035 Flux-Core

## 8-4. Error Displays



### Thermal Error

Indicates a malfunction in the primary power thermal protection circuit. If this display is shown, contact a Factory Authorized Service Agent.



### Thermal Error

Indicates a malfunction in the secondary thermal protection circuitry. If this display is shown, contact a Factory Authorized Service Agent.



### Overtemp

Indicates the unit has overheated. The unit has shut down to allow the fan to cool it (see Section 4-9). Operation will continue when the unit has cooled.



### Motor Error

Indicates a malfunction in the wire delivery circuit. Check wire tension, drive roll pressure or obstruction in gun liner.



### Fan Error

Indicates a malfunction in the fan cooling system. Check for an obstruction in the fan blades or if the fan motor is not operating properly.



### Shorted Trigger

Indicates a malfunction in the MIG gun or spoolgun trigger circuit or the four pin receptacle on front of the unit.



### Shorted Trigger

Indicates a malfunction in the foot control for the TIG process or in the eight pin RJ-45 connector on the front of the unit.



### Electrode Stuck

Indicates a stuck welding rod to the work piece while Stick welding. Clear short and recycle power.



### Electrode Stuck

Indicates a stuck Tungsten to the work piece while TIG welding. Clear short and recycle power.

## 8-5. Error Messages



Message	Error	Remedy
Overtemp-Please wait while the welder cools down.	Internal temperature of welder has exceeded the maximum limit.	Wait for unit to cool down. If the fan is not running, contact Miller Electric Mfg. LLC service department.
	The primary circuit thermistor is unplugged.	Reconnect the primary circuit thermistor.
	The secondary circuit thermistor is unplugged.	Reconnect the secondary circuit thermistor.
	The control board is damaged.	Contact Miller Electric Mfg. LLC service department.
	The primary circuit thermistor is reading too high or too low for a valid temperature.	Contact Miller Electric Mfg. LLC service department.
Motor error-Motor has drawn too much current.	The secondary circuit thermistor is reading too high or too low for a valid temperature.	Contact Miller Electric Mfg. LLC service department.
	Too much pressure on pressure adjust knob.	Reduce pressure on the pressure adjust knob.
	The gun liner is obstructed.	Clear obstruction or replace gun liner.
	The gun contact tip is obstructed.	Clear obstruction or replace contact tip.
	The welding wire is entangled.	Untangle welding wire.
Fan error-The fan is running too slow or is damaged.	The control board is damaged.	Contact Miller Electric Mfg. LLC service department.
	The fan blades are obstructed.	Clear obstruction from fan.
	The fan wiring harness is disconnected.	Connect the wiring harness
	The fan is damaged.	Contact Miller Electric Mfg. LLC service department.
Shorted trigger-Release 4-pin trigger to clear error.	The control board is damaged.	Contact Miller Electric Mfg. LLC service department.
	MIG gun or spool gun trigger is engaged on power up.	Release 4-pin trigger to clear error.
	MIG gun trigger is held during jog for more than 16 feet of wire.	
	Spool gun trigger is held during jog for more than 10 seconds.	
MIG gun or spool gun trigger is engaged for more than 1 second after the arc is broken.		
Shorted trigger-Release 4-pin trigger to clear error.	MIG gun or spool gun trigger is engaged while the process is changed to Flux Cored or a MIG process.	
	MIG gun or spool gun trigger leads are shorted together.	Fix or replace damaged gun.
Shorted trigger-Release 8-pin trigger to clear error.	The 8-pin trigger is engaged on power up.	Release the 8-pin trigger.
	The 8-pin trigger is engaged while the process is changed to TIG Lift-Arc Remote.	
Stuck electrode-Free stuck electrode to clear error.	Stick welding electrode has become stuck in weld puddle and turned output off.	Remove Stick welding electrode from workpiece and output will turn back on after about one second.
Stuck electrode-Free tungsten to clear error.	Tungsten electrode has become stuck in weld puddle and turned output off.	Remove the tungsten from workpiece and output will turn back on after about one second.
	Tungsten has contacted workpiece for more than 5 seconds without starting an arc.	

## 8-6. Troubleshooting



Trouble	Remedy
No weld output; unit completely inoperative.	Place line disconnect switch in On position.
	Check and replace line fuse(s), if necessary, or reset supplementary protector.
	Be sure power cord is plugged in and that receptacle is receiving input power.
No weld output; unit is on.	Check and secure loose weld cable(s) into receptacle(s).
	Check and correct poor connection of work clamp to workpiece.
Erratic or improper welding arc or output.	Use proper size and type of weld cable (see your Distributor).
	Clean and tighten weld connections.
	Verify electrode polarity; check and correct poor connections to workpiece.
Fan not operating.	Unit not warmed up enough to require fan cooling.
	Check for and remove anything blocking fan movement.
	Have Factory Authorized Service Agent check fan motor and control circuitry.
Stick welding problems: Hard starts; poor welding characteristics; unusual spattering.	Use proper type and size of electrode.
	Verify electrode polarity; check and correct poor connections.
	Make sure a remote control is not connected.
TIG welding problems: Wandering arc; hard starts; poor welding characteristics; spattering problems.	Use proper type and size of tungsten.
	Use properly prepared tungsten.
	Verify electrode polarity.
TIG welding problems: Tungsten electrode oxidizing and not remaining bright after welding.	Shield weld zone from drafts.
	Check for correct type shielding gas.
	Check and tighten gas fittings.
	Verify electrode polarity.



# SECTION 9 – ELECTRICAL DIAGRAM

	<b>WARNING</b> <ul style="list-style-type: none"> <li>Do not touch live electrical parts.</li> <li>Disconnect input power or stop engine before servicing.</li> <li>Do not operate with covers removed.</li> <li>Have only qualified persons install, use, or service this unit.</li> </ul>
	<b>ELECTRIC SHOCK HAZARD</b>





Figure 9-1. Circuit Diagram



# SECTION 10 – SELECTING AND PREPARING A TUNGSTEN FOR DC OR AC WELDING WITH INVERTER MACHINES

gtaw\_Inverter\_2018-01





Whenever possible and practical, use DC weld output instead of AC weld output.

## 10-1. Selecting Tungsten Electrode (Wear Clean Gloves To Prevent Contamination Of Tungsten)

### A. Select Tungsten Electrode.

 Not all tungsten electrode manufacturers use the same colors to identify tungsten type. Contact the tungsten electrode manufacturer or reference the product packaging to identify the tungsten you are using.

Electrode Diameter	Amperage Range - Gas Type♦ - Polarity	
	(DCEN) – Argon Direct Current Electrode Negative (For Use With Mild Or Stainless Steel)	AC – Argon Unbalanced Wave (For Use With Aluminum)
<b>2% Ceriated, 1.5% Lanthanum, Or 2% Thorium Alloy Tungstens</b>		
.010 in. (.25 mm)	Up to 15	Up to 15
.020 in. (.50 mm)	5-20	5-20
.040 in. (1 mm)	15-80	15-80
1/16 in. (1.6 mm)	70-150	70-150
3/32 in. (2.4 mm)	150-250	140-235
1/8 in. (3.2 mm)	250-400	225-325
5/32 in. (4.0 mm)	400-500	300-400
3/16 in (4.8 mm)	500-750	400-500
1/4 in. (6.4 mm)	750-1000	500-630

♦ Typical argon shielding gas flow rates are 10 to 25 CFH (cubic feet per hour).

Figures listed are a guide and are a composite of recommendations from American Welding Society (AWS).

### B. Electrode Composition.



Tungsten Type	Application Notes
2% Cerium (Grey*)	Good all-around tungsten for both AC and DC welding.
1.5–2% Lanthanum (Yellow/Blue)	Excellent low amp starts for AC and DC welding.
2% Thorium (Red)	Commonly used for DC welding, not ideal for AC.
Pure Tungsten (Green)	<b>Not Recommended for inverters!</b> For best results in most applications use a sharpened cerium or lanthanum electrode for AC and DC welding.

\* Color may vary depending on manufacturer, please refer to manufacturer's guide for color designation.

## 10-2. Preparing Tungsten Electrode For DC Electrode Negative (DCEN) Welding Or AC Welding With Inverter Machines



Grinding the tungsten electrode produces dust and flying sparks which can cause injury and start fires. Use local exhaust (forced ventilation) at the grinder or wear an approved respirator. Read MSDS for safety information. Consider using tungsten containing ceria, lanthana, or yttria instead of thoria. Grinding dust from thoriated electrodes contains low-level radioactive material. Properly dispose of grinder dust in an environmentally safe way. Wear proper face, hand, and body protection. Keep flammables away.



### 1 Grinding Wheel

Grind end of tungsten on fine grit, hard abrasive wheel before welding. Do not use wheel for other jobs or tungsten can become contaminated causing lower weld quality.

### 2 Tungsten Electrode

A 2% ceriated tungsten is recommended.

### 3 Ideal Grind Angle Range: 15° to 30°

☞ 30 degrees is the recommended electrode grind angle.


### 4 Straight Ground

Grind lengthwise, **not radial**.



# SECTION 11 – GUIDELINES FOR TIG WELDING (GTAW)

Ref. gtaw\_Phase\_2018-01

## 11-1. Positioning The Torch



**⚠** Grinding the tungsten electrode produces dust and flying sparks which can cause injury and start fires. Use local exhaust (forced ventilation) at the grinder or wear an approved respirator. Read MSDS for safety information. Consider using cerium or lanthanum based tungsten instead of thoriated. Thorium dust contains low-level radioactive material. Properly dispose of grinder dust in an environmentally safe way. Wear proper face, hand, and body protection. Keep flammables away.



- 1 Workpiece  
Make sure workpiece is clean before welding.
- 2 Work Clamp  
Place as close to the weld as possible.
- 3 Torch
- 4 Filler Rod (If Applicable)
- 5 Gas Cup
- 6 Tungsten Electrode

Select and prepare tungsten according to Section 10-2.

**Guidelines:**

The inside diameter of the gas cup should be at least three times the tungsten diameter to provide adequate shielding gas coverage. (For example, if tungsten is 1/16 in diameter, gas cup should be a minimum of 3/16 in diameter.


Tungsten extension is the distance the tungsten extends out gas cup of torch.

The tungsten extension should be no greater than the inside diameter of the gas cup.


Arc length is the distance from the tungsten to the workpiece.

Ref. 161892



## 11-2. Torch Movement During Welding



## 11-3. Positioning Torch Tungsten For Various Weld Joints



## 11-4. Lift-Arc And HF TIG Start Procedures



### Lift-Arc Start

When Lift-Arc™ button light is On, start arc as follows:

- 1 TIG Electrode
- 2 Workpiece

Touch tungsten electrode to workpiece at weld start point, enable output and shielding gas with torch trigger, foot control, or hand control. **Hold electrode to workpiece for 1-2 seconds**, and slowly lift electrode. Arc is formed when electrode is lifted.

Normal open-circuit voltage is not present before tungsten electrode touches workpiece; only a low sensing voltage is present between electrode and workpiece. The solid-state output contactor does not energize until after electrode is touching workpiece. This allows electrode to touch workpiece without overheating, sticking, or getting contaminated.

### Application:

Lift-Arc is used for the DCEN or AC GTAW process when HF Start method is not permitted, or to replace the scratch method.

### HF Start

When HF Start button light is On, start arc as follows:


High frequency turns on to help start arc when output is enabled. High frequency turns off when arc is started, and turns on whenever arc is broken to help restart arc.

### Application:

HF start is used for the DCEN GTAW process when a non-contact arc starting method is required.

# SECTION 12 – GMAW WELDING (MIG) GUIDELINES

## 12-1. Typical GMAW (MIG) Process Connections



## 12-2. Typical GMAW (MIG) Process Control Settings

1 Material Thickness  
Material thickness determines weld parameters.  
Convert material thickness to amperage (A):  
0.001 in. (0.025 mm) = 1 ampere  
0.0625 in. (1.59 mm) ÷ 0.001 = 62.5 A

2 Select Wire Size  
See table below.

3 Select Wire Feed Speed (Amperage)  
Wire feed speed (amperage) controls weld penetration.  
See table below.

4 Select Voltage  
Voltage controls height and width of weld bead.  
Low Voltage: wire stubs into work  
High Voltage: arc is unstable (spatter)  
Set voltage midway between high and low voltage.

Wire Size	Amperage Range	Recommended Wire Feed Speed	Wire Feed Speed*
0.023 in. (0.58 mm)	30–90 A	3.5 in. (89 mm) per amp	3.5 x 62.5 A = 219 ipm (5.56 mpm)
0.030 in. (0.76 mm)	40–145 A	2 in. (51 mm) per amp	2 x 62.5 A = 125 ipm (3.19 mpm)
0.035 in. (0.89 mm)	50–180 A	1.6 in. (41 mm) per amp	1.6 x 62.5 A = 100 ipm (2.56 mpm)


\*62.5 A based on 1/16 in. (1.6 mm) material thickness.

ipm = inches per minute; mpm = meters per minute


### 12-3. Holding And Positioning Welding Gun




☞ Welding wire is energized when gun trigger is pressed. Before lowering helmet and pressing trigger, be sure wire is no more than 1/2 in. (13 mm) past end of nozzle, and tip of wire is positioned correctly on seam.



- 1 Hold Gun and Control Gun Trigger
- 2 Workpiece
- 3 Work Clamp
- 4 Electrode Extension (Stickout)  
Solid Wire – 3/8 to 1/2 in.  
(9 to 13 mm)
- 5 Cradle Gun and Rest Hand on Workpiece




End View of Work Angle




Side View of Gun Angle

Groove Welds



End View of Work Angle



Side View of Gun Angle


Fillet Welds

S-0421-A


### 12-4. Conditions That Affect Weld Bead Shape




☞ Weld bead shape depends on gun angle, direction of travel, electrode extension (stickout), travel speed, thickness of base metal, wire feed speed (weld current), and voltage.




Gun Angles And Weld Bead Profiles



Electrode Extensions (Stickout)





Fillet Weld Electrode Extensions (Stickout)



Gun Travel Speed

S-0634

## 12-5. Gun Movement During Welding





Normally, a single stringer bead is satisfactory for most narrow groove weld joints; however, for wide groove weld joints or bridging across gaps, a weave bead or multiple stringer beads works better.

- 1 Stringer Bead – Steady Movement Along Seam
- 2 Weave Bead – Side To Side Movement Along Seam
- 3 Weave Patterns

Use weave patterns to cover a wide area in one pass of the electrode.

S-0054-A


## 12-6. Poor Weld Bead Characteristics



- 1 Large Spatter Deposits
- 2 Rough, Uneven Bead
- 3 Slight Crater During Welding
- 4 Bad Overlap
- 5 Poor Penetration

S-0053-A

## 12-7. Good Weld Bead Characteristics




- 1 Fine Spatter
- 2 Uniform Bead
- 3 Moderate Crater During Welding

Weld a new bead or layer for each 1/8 in. (3.2 mm) thickness in metals being welded.

- 4 No Overlap
- 5 Good Penetration into Base Metal

S-0052-B

## 12-8. Troubleshooting – Excessive Spatter




Excessive Spatter – scattering of molten metal particles that cool to solid form near weld bead.

S-0636

Possible Causes	Corrective Actions
Wire feed speed too high.	Select lower wire feed speed.
Voltage too high.	Select lower voltage range.
Electrode extension (stickout) too long.	Use shorter electrode extension (stickout).
Workpiece dirty.	Remove all grease, oil, moisture, rust, paint, undercoating, and dirt from work surface before welding.
Insufficient shielding gas at welding arc.	Increase flow of shielding gas at regulator/flowmeter and/or prevent drafts near welding arc.
Dirty welding wire.	Use clean, dry welding wire.
	Eliminate pickup of oil or lubricant on welding wire from feeder or liner.
Incorrect polarity.	Check polarity required by welding wire, and change to correct polarity at welding power source.

## 12-9. Troubleshooting – Porosity




Porosity – small cavities or holes resulting from gas pockets in weld metal.

S-0635

Possible Causes	Corrective Actions
Insufficient shielding gas at welding arc.	Increase flow of shielding gas at regulator/flowmeter and/or prevent drafts near welding arc.
	Remove spatter from gun nozzle.
	Check gas hoses for leaks.
	Place nozzle 1/4 to 1/2 in. (6-13 mm) from workpiece.
	Hold gun near bead at end of weld until molten metal solidifies.
Wrong gas.	Use welding grade shielding gas; change to different gas.
Dirty welding wire.	Use clean, dry welding wire.
	Eliminate pick up of oil or lubricant on welding wire from feeder or liner.
Workpiece dirty.	Remove all grease, oil, moisture, rust, paint, coatings, and dirt from work surface before welding.
	Use a more highly deoxidizing welding wire (contact supplier).
Welding wire extends too far out of nozzle.	Be sure welding wire extends not more than 1/2 in. (13 mm) beyond nozzle.

## 12-10. Troubleshooting – Excessive Penetration




Excessive Penetration Good Penetration

Excessive Penetration – weld metal melting through base metal and hanging underneath weld.

S-0639


Possible Causes	Corrective Actions
Excessive heat input.	Select lower voltage range and reduce wire feed speed.
	Increase travel speed.

## 12-11. Troubleshooting – Lack Of Penetration




Possible Causes	Corrective Actions
Improper joint preparation.	Material too thick. Joint preparation and design must provide access to bottom of groove while maintaining proper welding wire extension and arc characteristics.
Improper weld technique.	Maintain normal gun angle of 0 to 15 degrees to achieve maximum penetration.
	Keep arc on leading edge of weld puddle.
	Be sure welding wire extends not more than 1/2 in. (13 mm) beyond nozzle.
Insufficient heat input.	Select higher wire feed speed and/or select higher voltage range.
	Reduce travel speed.
Incorrect polarity.	Check polarity required by welding wire, and change to correct polarity at welding power source.

## 12-12. Troubleshooting – Incomplete Fusion



Possible Causes	Corrective Actions
Workpiece dirty.	Remove all grease, oil, moisture, rust, paint, undercoating, and dirt from work surface before welding.
Insufficient heat input.	Select higher voltage range and/or adjust wire feed speed.
Improper welding technique.	Place stringer bead in proper location(s) at joint during welding.
	Adjust work angle or widen groove to access bottom during welding.
	Momentarily hold arc on groove side walls when using weaving technique.
	Keep arc on leading edge of weld puddle.
	Use correct gun angle of 0 to 15 degrees.

## 12-13. Troubleshooting – Burn-Through



Possible Causes	Corrective Actions
Excessive heat input.	Select lower voltage range and reduce wire feed speed.
	Increase and/or maintain steady travel speed.



## 12-16. Common GMAW (MIG) Shielding Gases

This is a general chart for common gases and where they are used. Many different combinations (mixtures) of shielding gases have been developed over the years. The most commonly used shielding gases are listed in the following table.

Gas	Application								
	Spray Arc Steel	Short Circuiting Steel	GMAW-P Steel	Spray Arc Stainless Steel	Short Circuiting Stainless Steel	GMAW-P Stainless Steel	Spray Arc Aluminum	Short Circuiting Aluminum	GMAW-P Aluminum
Argon			All Positions				All Positions	All Positions	All Positions
Argon + 1% O <sub>2</sub>	Flat & Horizontal Fillet		All Positions	Flat & Horizontal Fillet					
Argon + 2% O <sub>2</sub>	Flat & Horizontal Fillet		All Positions	Flat & Horizontal Fillet					
Argon + 5% CO <sub>2</sub>	Flat & Horizontal Fillet		All Positions						
Argon + 10% CO <sub>2</sub>	Flat & Horizontal Fillet	All Positions	All Positions						
Argon + 25% CO <sub>2</sub>		All Positions							
Argon + 50% CO <sub>2</sub>		All Positions							
CO <sub>2</sub>		All Positions							
Helium							All Positions <sup>1</sup>		
Argon + Helium							All Positions <sup>1</sup>		
90% HE + 7-1/2% AR + 2-1/2% CO <sub>2</sub>					All Positions				
65% AR + 33% HE + 2% CO <sub>2</sub>						All Positions			

1 Heavy Thicknesses

## 12-17.

**Troubleshooting Guide For Semiautomatic Welding Equipment**


<b>Problem</b>	<b>Probable Cause</b>	<b>Remedy</b>
Wire feed motor operates, but wire does not feed.	Too little pressure on wire feed rolls.	Increase pressure setting on wire feed rolls.
	Incorrect wire feed rolls.	Check size stamped on wire feed rolls, replace to match wire size and type if necessary.
	Wire spool brake pressure too high.	Decrease brake pressure on wire spool.
	Restriction in the gun and/or assembly.	Check and replace cable, gun, and contact tip if damaged. Check size of contact tip and cable liner, replace if necessary.
Wire curling up in front of the wire feed rolls (bird nesting).	Too much pressure on wire feed rolls.	Decrease pressure setting on wire feed rolls.
	Incorrect cable liner or gun contact tip size.	Check size of contact tip and check cable liner length and diameter, replace if necessary.
	Gun end not inserted into drive housing properly.	Loosen gun securing bolt in drive housing and push gun end into housing just enough so it does not touch wire feed rolls.
	Dirty or damaged (kinked) liner.	Replace liner.
Wire feeds, but no gas flows.	Gas cylinder empty.	Replace empty gas cylinder.
	Gas nozzle plugged.	Clean or replace gas nozzle.
	Gas cylinder valve not open or flowmeter not adjusted.	Open gas valve at cylinder and adjust flow rate.
	Restriction in gas line.	Check gas hose between flowmeter and wire feeder, and gas hose in gun and cable assembly.
	Loose or broken wires to gas solenoid.	Have Factory Authorized Service Agent repair wiring.
	Gas solenoid valve not operating.	Have Factory Authorized Service Agent replace gas solenoid valve.
	Incorrect primary voltage connected to welding power source.	Check primary voltage and relink welding power source for correct voltage.
Welding arc not stable.	Wire slipping in drive rolls.	Adjust pressure setting on wire feed rolls. Replace worn drive rolls if necessary.
	Wrong size gun liner or contact tip.	Match liner and contact tip to wire size and type.
	Incorrect voltage setting for selected wire feed speed on welding power source.	Readjust welding parameters.
	Loose connections at the gun weld cable or work cable.	Check and tighten all connections.
	Gun in poor shape or loose connection inside gun.	Repair or replace gun as necessary.

# SECTION 13 – GUIDELINES FOR STICK WELDING (SMAW)


## 13-1. Stick Welding Procedure




Tools Needed:



Equipment Needed:



Constant Current  
Welding Power Source



**⚠** Weld current starts when electrode touches work-piece.

**⚠** Weld current can damage electronic parts in vehicles. Disconnect both battery cables before welding on a vehicle. Place work clamp as close to the weld as possible.

**📖** Always wear appropriate personal protective clothing.

1 Workpiece

Make sure workpiece is clean before welding.

2 Work Clamp

Place as close to the weld as possible.

3 Electrode

Before striking an arc, insert an electrode in the electrode holder. A small diameter electrode requires less current than a large one. Follow recommendations of the electrode manufacturer when setting weld amperage (see Section 13-2).

4 Insulated Electrode Holder

5 Electrode Holder Position

6 Arc Length


Arc length is the distance from the electrode to the workpiece. A short arc with correct amperage will give a sharp, crackling sound. Correct arc length is related to electrode diameter. Examine the weld bead to determine if the arc length is correct.

Arc length for 1/16 and 3/32 in. diameter electrodes should be about 1/16 in. (1.6 mm); arc length for 1/8 and 5/32 in. electrodes should be about 1/8 in. (3 mm).

7 Slag

Use a chipping hammer and wire brush to remove slag. Remove slag and check weld bead before making another weld pass.

## 13-2. Electrode And Amperage Selection Chart




ELECTRODE	DIAMETER	AMPERAGE RANGE								
		50	100	150	200	250	300	350	400	450
6010 & 6011	3/32	■								
	1/8		■							
	5/32			■						
	3/16				■					
	7/32					■				
6013	1/4					■				
	1/16	■								
	5/64		■							
	3/32			■						
	1/8				■					
	5/32					■				
	3/16						■			
	7/32							■		
	1/4								■	
	3/32									■
7014	1/8									■
	5/32									
	3/16									
	7/32									
	1/4									
7018	3/32									■
	1/8									
	5/32									
	3/16									
	7/32									
7024	1/4									■
	3/32									
	1/8									
	5/32									
	3/16									
Ni-CI	7/32									■
	1/4									
	3/32									
	1/8									
	5/32									
308L	3/16									■
	1/8									
	5/32									

ELECTRODE	DC*	AC	POSITION	PENETRATION	USAGE
6010	EP		ALL	DEEP	MIN. PREP. ROUGH HIGH SPATTER
6011	EP	✓	ALL	DEEP	
6013	EP,EN	✓	ALL	LOW	GENERAL
7014	EP,EN	✓	ALL	MED	SMOOTH, EASY, FAST
7018	EP	✓	ALL	MED	LOW HYDROGEN, STRONG
7024	EP,EN	✓	FLAT HORIZ*	LOW	SMOOTH, EASY, FASTER
NI-CL	EP	✓	ALL	LOW	CAST IRON
308L	EP	✓	ALL	LOW	STAINLESS

\*EP = ELECTRODE POSITIVE (REVERSE POLARITY)  
EN = ELECTRODE NEGATIVE (STRAIGHT POLARITY)

Ref. S-087 985-A

## 13-3. Striking An Arc



**⚠ Weld current starts when electrode touches workpiece.**

- 1 Electrode
- 2 Workpiece
- 3 Arc

### Scratch Technique




Drag electrode across workpiece like striking a match; lift electrode slightly after touching work. If arc goes out, electrode was lifted too high. If electrode sticks to workpiece, use a quick twist to free it.

### Tapping Technique

Bring electrode straight down to workpiece; then lift slightly to start arc. If arc goes out, electrode was lifted too high. If electrode sticks to workpiece, use a quick twist to free it.

S-0049 / S-0050

### 13-4. Positioning Electrode Holder



- 1 End View Of Work Angle
- 2 Side View Of Electrode Angle


After learning to start and hold an arc, practice running beads of weld metal on flat plates using a full electrode.

Hold the electrode nearly perpendicular to the work, although tilting it ahead (in the direction of travel) will be helpful.

*To produce the best results, hold a short arc, travel at a uniform speed, and feed the electrode downward at a constant rate as it melts.*

S-0060


### 13-5. Poor Weld Bead Characteristics



- 1 Large Spatter Deposits
- 2 Rough, Uneven Bead
- 3 Slight Crater During Welding
- 4 Bad Overlap
- 5 Poor Penetration

S-0053-A

### 13-6. Good Weld Bead Characteristics




- 1 Fine Spatter
- 2 Uniform Bead
- 3 Moderate Crater During Welding

Weld a new bead or layer for each 1/8 in. (3.2 mm) thickness in metals being welded.

- 4 No Overlap
- 5 Good Penetration into Base Metal

S-0052-B

### 13-7. Conditions That Affect Weld Bead Shape



☞ *Weld bead shape is affected by electrode angle, arc length, travel speed, and thickness of base metal.*

**Electrode Angle**

Angle Too Small      Correct Angle  $10^{\circ} - 30^{\circ}$       Angle Too Large

→ Drag

**Arc Length**

Too Short      Normal      Too Long (Spatter)

**Travel Speed**

Slow      Normal      Fast

S-0061

### 13-8. Electrode Movement During Welding



☞ *Normally, a single stringer bead is satisfactory for most narrow groove weld joints; however, for wide groove weld joints or bridging across gaps, a weave bead or multiple stringer beads work better.*

1 Stringer Bead – Steady Movement Along Seam

2 Weave Bead – Side to Side Movement Along Seam

3 Weave Patterns

Use weave patterns to cover a wide area in one pass of the electrode. Do not let weave width exceed 2-1/2 times diameter of electrode.

S-0054-A

### 13-9. Welding Lap Joints



1 Electrode

2 Single-Layer Fillet Weld


Move electrode in circular motion.

3 Multi-Layer Fillet Weld

Weld a second layer when a heavier fillet is needed. Remove slag before making another weld pass. Weld both sides of joint for maximum strength.

S-0063 / S-0064

## 13-10. Welding Groove (Butt) Joints



### 1 Tack Welds

Prevent butt joint distortion by tack welding the materials in position before final weld.

Workpiece distortion occurs when heat is applied locally to a joint. One side of a metal plate will curl up toward the weld. Distortion will also cause the edges of a butt joint to pull together ahead of the electrode as the weld cools.

### 2 Square Groove Weld

### 3 Single V-Groove Weld


### 4 Double V-Groove Weld

Materials up to 3/16 in. (5 mm) thick can often be welded without special preparation using the square groove weld. However, when welding thicker materials it may be necessary to prepare the edges (V-groove) of butt joints to ensure good welds.

The single or double V-groove weld is good for materials 3/16 – 3/4 in. (5-19 mm) thick. Generally, the single V-groove is used on materials up to 3/4 in. (19 mm) thick and when, regardless of thickness, you can weld from one side only. Create a 30 degree bevel with oxy-acetylene or plasma cutting equipment. Remove scale from material after cutting. A grinder can also be used to prepare bevels.

S-0062

## 13-11. Welding T-Joints



### 1 Electrode

### 2 Fillet Weld

Keep arc short and move at definite rate of speed. Hold electrode as shown to provide fusion into the corner. Square edge of the weld surface.


For maximum strength weld both sides of upright section.


### 3 Multi-Layer Deposits


Weld a second layer when a heavier fillet is needed. Use any of the weaving patterns shown in Section 13-8. Remove slag before making another weld pass.

S-0060 / S-0058-A / S-0061

### 13-12. Weld Test







- 1 Vise
- 2 Weld Joint
- 3 Hammer

Strike the weld joint in the direction shown. A good weld bends over but does not break.

If the weld breaks, examine it to determine the cause.




If the weld is porous (many holes), the arc length was probably too long.






If the weld contains bits of slag, the arc may have been too long or the electrode was moved incorrectly which allowed molten slag to be trapped in the weld. This may happen on a V-groove joint made in several layers and calls for additional cleaning between layers.

If the original beveled surface is visible the material was not fully melted which is often caused by insufficient heat or too fast a travel speed.

S-0057-B

### 13-13. Troubleshooting

	<p><b>Porosity</b> – small cavities or holes resulting from gas pockets in weld metal.</p>
<b>Possible Causes</b>	<b>Remedy</b>
Arc length too long.	Reduce arc length.
Damp electrode.	Use dry electrode.
Workpiece dirty.	Remove all grease, oil, moisture, rust, paint, coatings, slag, and dirt from work surface before welding.
	<p><b>Excessive Spatter</b> – scattering of molten metal particles that cool to solid form near weld bead.</p>
<b>Possible Causes</b>	<b>Remedy</b>
Amperage too high for electrode.	Decrease amperage or select larger electrode.
Arc length too long or voltage too high.	Reduce arc length or voltage.
	<p><b>Incomplete Fusion</b> – failure of weld metal to fuse completely with base metal or a preceding weld bead.</p>
<b>Possible Causes</b>	<b>Remedy</b>
Insufficient heat input.	Increase amperage. Select larger electrode and increase amperage.
Improper welding technique.	Place stringer bead in proper location(s) at joint during welding.
	Adjust work angle or widen groove to access bottom during welding.
	Momentarily hold arc on groove side walls when using weaving technique.
	Keep arc on leading edge of weld puddle.
Workpiece dirty.	Remove all grease, oil, moisture, rust, paint, coatings, slag, and dirt from work surface before welding.

 <p>Lack of Penetration      Good Penetration</p>	<p><b>Lack Of Penetration</b> – shallow fusion between weld metal and base metal.</p>
<p><b>Possible Causes</b></p>	<p><b>Remedy</b></p>
<p>Improper joint preparation.</p>	<p>Material too thick. Joint preparation and design must provide access to bottom of groove.</p>
<p>Improper weld technique.</p>	<p>Keep arc on leading edge of weld puddle.</p>
<p>Insufficient heat input.</p>	<p>Increase amperage. Select larger electrode and increase amperage.</p>
	<p>Reduce travel speed.</p>
 <p>Excessive Penetration      Good Penetration</p>	<p><b>Excessive Penetration</b> – weld metal melting through base metal and hanging underneath weld.</p>
<p><b>Possible Causes</b></p>	<p><b>Remedy</b></p>
<p>Excessive heat input.</p>	<p>Select lower amperage. Use smaller electrode.</p>
	<p>Increase and/or maintain steady travel speed.</p>
	<p><b>Burn-Through</b> – weld metal melting completely through base metal resulting in holes where no metal remains.</p>
<p><b>Possible Causes</b></p>	<p><b>Remedy</b></p>
<p>Excessive heat input.</p>	<p>Select lower amperage. Use smaller electrode.</p>
	<p>Increase and/or maintain steady travel speed.</p>
	<p><b>Waviness Of Bead</b> – weld metal that is not parallel and does not cover joint formed by base metal.</p>
<p><b>Possible Causes</b></p>	<p><b>Remedy</b></p>
<p>Unsteady hand.</p>	<p>Use two hands. Practice technique.</p>
 <p>Base metal moves in the direction of the weld bead.</p>	<p><b>Distortion</b> – contraction of weld metal during welding that forces base metal to move.</p>
<p><b>Possible Causes</b></p>	<p><b>Remedy</b></p>
<p>Excessive heat input.</p>	<p>Use restraint (clamp) to hold base metal in position.</p>
	<p>Make tack welds along joint before starting welding operation.</p>
	<p>Select lower amperage for electrode.</p>
	<p>Increase travel speed.</p>
	<p>Weld in small segments and allow cooling between welds.</p>

# SECTION 14 – PARTS LIST

## 14-1. Parts List

Item No.	Dia. Mkgs.	Part No.	Description	Quantity
<b>Multi-Handler 200</b>				
... 1	... PC6	.. 287964	.. Circuit Card Assy, LCD	1
... 2	... PC5	.. 287965	.. Circuit Card Assy, Encoder	1
... 3	.. PC10	.. 287966	.. Circuit Card Assy, RJ45	1
... 4	... PC4	.. 287967	.. Circuit Card Assy, Control	1
... 5	... PC1	.. 287968	.. Circuit Card Assy, Power	1
... 6	... PC8	.. 287969	.. Circuit Card Assy, EMC Filter	1
... 7	... PC3	.. 287970	.. Circuit Card Assy, Motor Control	1
... 8	... PC7	.. 287971	.. Circuit Card Assy, Output Diodes	1
... 9		.. 282972	.. Valve, Gas w/Clamps	1
... 10		.. 282973	.. Bezel, Front w/Nameplate	1
... 11		.. 282974	.. Wrapper, Cover w/Labels	1

**To maintain the factory original performance of your equipment, use only Manufacturer's Suggested Replacement Parts. Model and serial number required when ordering parts from your local distributor.**

## 14-2. Recommended MIG Spare Parts

Part No.	Description	Quantity
..... 261157	..... Roll, Drive .024, .030-.035V Wire, .035VK Wire	1
..... ♦202926	..... Roll, Drive VK .030-.035/.045 Wire	1
..... 271493	..... Lens Cover, Replaceable	1

♦OPTIONAL

**To maintain the factory original performance of your equipment, use only Manufacturer's Suggested Replacement Parts. Model and serial number required when ordering parts from your local distributor.**

☞ See OM-282976 (shipped with this product) for replacement consumables for MDX welding gun.

## 14-3. Recommended TIG Spare Parts

Part No.	Description	Quantity
..... WP1712RDI25	..... Tig Torch, A-150 12.5FT	1
..... 194744	..... Foot Control, RFCS-14HD	1
..... AK2C	..... Accessory Kit, Ceriated	1
..... AK-150MFC	..... Accessory Kit, FX	1

☞ A complete Parts List is available online at [www.MillerWelds.com](http://www.MillerWelds.com)





Effective January 1, 2020

*Warranty Questions?*

Call  
1-800-332-3281  
8 AM – 5 PM EST

**Service**

You always get the fast, reliable response you need. Most replacement parts can be in your hands in 24 hours.

**Support**

Need fast answers to the tough welding questions? Contact your distributor or call 1-800-332-3281. The expertise of the distributor and Hobart is there to help you, every step of the way.

**Assistance**

Visit the Hobart website:  
[www.HobartWelders.com](http://www.HobartWelders.com)

5/3/1 WARRANTY applies to all Hobart welding equipment, plasma cutters and spot welders with a serial number preface of NA or newer.

This limited warranty supersedes all previous Hobart warranties and is exclusive with no other guarantees or warranties expressed or implied.  
Hobart products are serviced by Hobart or Miller Authorized Service Agencies.

LIMITED WARRANTY – Subject to the terms and conditions below, Miller Electric Mfg. LLC, dba Hobart Welding Products, Appleton, Wisconsin, warrants to its original retail purchaser that new Hobart equipment sold after the effective date of this limited warranty is free of defects in material and workmanship at the time it is shipped. THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS.

Within the warranty periods listed below, Hobart/Miller will repair or replace any warranted parts or components that fail due to such defects in material or workmanship. Hobart/Miller must be notified in writing within thirty (30) days of such defect or failure, at which time Hobart/Miller will provide instructions on the warranty claim procedures to be followed. Notifications submitted as online warranty claims must provide detailed descriptions of the fault and troubleshooting steps taken to diagnose failed parts. Warranty claims that lack the required information as defined in the Miller Service Operation Guide (SOG) may be denied by Miller.

Hobart/Miller shall honor warranty claims on warranted equipment listed below in the event of a defect within the warranty coverage time periods listed below. Warranty time periods start on the delivery date of the equipment to the original retail purchaser, or 12 months after the equipment is shipped to a North American or international distributor, whichever occurs first.

1. 5 Years — Parts and Labor
  - \* Original Main Power Rectifiers only to include SCRs, diodes, and discrete rectifier modules
  - \* Reactors
  - \* Stabilizers
  - \* Transformers
2. 3 Years — Parts and Labor Unless Specified
  - \* Drive Systems
  - \* Idle Module
  - \* PC Boards
  - \* Rotors, Stators and Brushes
  - \* Solenoid Valves
  - \* Switches and Controls
3. 1 Year — Parts and Labor Unless Specified (90 days for industrial use)
  - \* Accessories (Kits)
  - \* Contactors
  - \* Field Options  
(NOTE: Field options are covered for the remaining warranty period of the product they are installed in, or for a minimum of one year — whichever is greater.)
  - \* HF Units
  - \* MIG Flowgauge Regulators (No Labor)
  - \* MIG Guns/TIG Torches
  - \* Motor-Driven Guns
  - \* Plasma Cutting Torches
  - \* Relays
  - \* Remote Controls
  - \* Replacement Parts (No labor) – 90 days
  - \* Running Gear/Trailers
  - \* Spoolguns

4. 6 Months — Parts
  - \* Batteries
5. Engines and tires are warranted separately by the manufacturer.

Hobart's 5/3/1 Limited Warranty shall not apply to:

1. **Consumable components; such as contact tips, cutting nozzles, contactors, brushes, relays, work station table tops and welding curtains, or parts that fail due to normal wear. (Exception: brushes and relays are covered on all engine-driven products.)**
2. Items furnished by Hobart/Miller, but manufactured by others, such as engines or trade accessories. These items are covered by the manufacturer's warranty, if any.
3. Equipment that has been modified by any party other than Hobart/Miller, or equipment that has been improperly installed, improperly operated or misused based upon industry standards, or equipment which has not had reasonable and necessary maintenance, or equipment which has been used for operation outside of the specifications for the equipment.
4. Defects caused by accident, unauthorized repair, or improper testing.

HOBART PRODUCTS ARE INTENDED FOR COMMERCIAL AND INDUSTRIAL USERS TRAINED AND EXPERIENCED IN THE USE AND MAINTENANCE OF WELDING EQUIPMENT.

The exclusive remedies for warranty claims are, at Hobart's/Miller's option, either: (1) repair; or (2) replacement; or, if approved in writing by Hobart/Miller, (3) the pre-approved cost of repair or replacement at an authorized Hobart/Miller service station; or (4) payment of or credit for the purchase price (less reasonable depreciation based upon use). Products may not be returned without Hobart's/Miller's written approval. Return shipment shall be at customer's risk and expense.

The above remedies are F.O.B. Appleton, WI, or Hobart's/Miller's authorized service facility. Transportation and freight are the customer's responsibility. TO THE EXTENT PERMITTED BY LAW, THE REMEDIES HEREIN ARE THE SOLE AND EXCLUSIVE REMEDIES REGARDLESS OF THE LEGAL THEORY. IN NO EVENT SHALL HOBART/MILLER BE LIABLE FOR DIRECT, INDIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES (INCLUDING LOSS OF PROFIT) REGARDLESS OF THE LEGAL THEORY. ANY WARRANTY NOT PROVIDED HEREIN AND ANY IMPLIED WARRANTY, GUARANTY, OR REPRESENTATION, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR PARTICULAR PURPOSE, ARE EXCLUDED AND DISCLAIMED BY HOBART/MILLER.

Some US states do not allow limiting the duration of an implied warranty or the exclusion of certain damages, so the above limitations may not apply to you. This warranty provides specific legal rights, and other rights may be available depending on your state. In Canada, some provinces provide additional warranties or remedies, and to the extent the law prohibits their waiver, the limitations set out above may not apply. This Limited Warranty provides specific legal rights, and other rights may be available, but may vary by province.



# Owner's Record

Please complete and retain with your personal records.

Model Name

Serial/Style Number

Purchase Date

(Date which equipment was delivered to original customer.)

Distributor

Address

City

State

Zip



Thank you for purchasing Hobart. Our trained technical support team is dedicated to your satisfaction. For questions regarding performance, operation, or service, contact us!

## Resources Available

Always provide Model Name and Serial/Style Number.

### To locate a Service Center:

Call 1-800-332-3281

or visit our website at [www.HobartWelders.com/wheretobuy](http://www.HobartWelders.com/wheretobuy)

### For Technical Assistance:

Call 1-800-332-3281

8 AM to 5 PM EST – Monday through Friday

#### Miller Electric Mfg. LLC

An Illinois Tool Works Company  
1635 West Spencer Street  
Appleton, WI 54914 USA

#### For Assistance:

Call 1-800-332-3281

